



INSTALLATION & SERVICING

EQMAX

MODELS

S20

S25

S30

M35

M50

M60

L70

L80

L100

L120

When replacing any part on this appliance, use only spare parts that you can be assured conform to the safety and performance specification that we require. Do not use reconditioned or copy parts that have not been clearly authorised by Ideal Heating.

For the very latest copy of literature for specification and maintenance practices visit our website idealheating.com where you can download the relevant information in PDF format.



CONTENTS

Symbols used in this document.....	4
1. WARNINGS AND RECOMMENDATIONS.....	5
1.1. Transport and storage	5
1.2. Qualification of personnel for installation, adjustment, operation and maintenance	5
1.3. Handling.....	6
1.4. Safety instructions.....	7
1.5. Water composition.....	8
2. APPROVALS	8
2.1. Compliance with European Directives	8
2.2. Gas category	11
2.3. Gas supply pressures	11
3. TECHNICAL SPECIFICATIONS	12
3.1. Dimensions	12
3.2. Boiler components	14
3.3. Combustion at 15°C and 1013 mbar.....	16
3.4. Operating conditions	22
3.5. Electrical connection	22
4. INSTALLATION	23
4.1. Ventilation.....	23
4.2. Unvented installation.....	23
4.3. Vented installation.....	25
4.4. Removing the cover panel	26
4.5. Installing the EQMAX	26
4.6. Flue installation connection.....	27
4.7. Hydraulic connection.....	31
4.8. Gas change G20-G31	32
4.9. Gas connection	38
4.10. Electrical connection / Wiring diagram	38
5. START-UP	43
5.1. Filling the boiler	43
5.2. Starting-up.....	43
6. CHECKS AFTER COMMISSIONING.....	43
6.1. Condensate removal	43
6.2. Gas supply	43

7. MAINTENANCE OPERATIONS	44
7.1. Descaling and cleaning of the storage tank	45
7.2. Checking the ignition and ionisation electrodes	45
7.3. Cleaning the condensate evacuation pipe	46
7.4. Checking the combustion circuit seal	46
7.5. Checking the combustion quality	47
7.6. Checking the gas valve setting	48
7.7. Cleaning the burner and the evacuation in the by-pass and changing the seals	49
8. HYDRAULIC DIAGRAMS AND CONFIGURATIONS	52
9. ELECTRICAL VALIDATION	81
10. OPTIMISATION	81
11. SPARE PARTS LIST	85
12. CUSTOMER REGULATION PARAMETERS TABLE	94
13. ANNEXE A PRODUCT FICHE	103

Symbols used in this document

**INFORMATION:**

This symbol draws attention to comments.

**CAUTION:**

May cause damage to the installation or to other objects.

**WARNING:**

May cause injury and serious material damage.

**DANGER:**

May cause electrocution.

The EQMAX is covered by Section G3 of the Building Regulations (England and Wales) Technical Standard P3 (Scotland) and Building Regulation P5 (Northern Ireland). Compliance can be achieved via a Competent Person Self Certification Scheme or notification of installation to the Local Authority Building Control Department.

It must be installed by a competent person as defined by the relevant regulations. Manufacturers notes must NOT be taken as overriding statutory obligations

1. WARNINGS AND RECOMMENDATIONS

To install, adjust and maintain the water heater, it must be carried out by a qualified and approved professional in accordance with current local and national regulations. These operations may require working on the hot water storage heater with the mains power on and the casing control cover removed, all necessary precautions must be taken. The water heater must always have the external covers fitted when put into operation.

1.1. Transport and storage

The water heater :

- must be stored vertically at a temperature of between -20 °C and +60 °C, with a relative humidity of between 5% and 95%.
- must not be stacked,
- must be protected from humidity.
- must not be exposed to the sun.
- must be transported vertically.
- must not be slung.
- must be removed from its pallet for any tilted or horizontal handling. In this case, the installer will carefully protect the product to avoid any damage during this handling.


1.2. Qualification of personnel for installation, adjustment, operation and maintenance

Boiler installation, adjustment and maintenance must be conducted by a Gas Safe installer (UK) or Registered Gas Installer (IE) . Operations may require work to be carried out with the power turned on and the casing open. Basic operations must be carried out with the casing closed.

1.3. Handling

The EQMAX must only be handled/moved using a pallet truck or a hand truck (see §3.4 for water heater weight). If the latter is used, the following handling recommendations **MUST BE** respected:

- Position the three-wheeled hand truck and the strap:



INFORMATION:

In order to move the EQMAX LXX model through an 800 mm passageway, you will have to dismantle the top, the screen, the cable gland plate and the TDC bracket, the jacket and associated covers, and the display support.




figure 1 - Transporting through a doorway - EQMAX LXX model



WARNING :

Ensure that the EQMAX is positioned as shown on the hand-truck in the diagrams above.



IMPORTANT :

To avoid damaging the EQMAX, we strongly recommend protecting it where it is in contact with the hand truck and the strap ratchet..

1.4. Safety instructions

- Always disconnect the EQMAX from the power supply and shut off the main gas supply before carrying out any work on it.
- Check that there are no gas leaks on the installation after any work on the EQMAX (maintenance or repair).

**WARNING:**

If you smell gas:

Where safe to do so :

- Turn off the gas supply at the emergency/meter control valve (ECV/ MCV).
- Extinguish and remove all sources of ignition.
- Ensure that any electrical switches are not operated either off or on.
- Ventilate the building by opening doors and windows to ensure an adequate air flow direct from outside.
- Perform an appropriate tightness test on the gas installation
- Where the tightness test indicates a gas escape exists, proceed to locate and repair the escape.
- If the source of the gas escape cannot be repaired there and then, make the installation safe and apply the procedures contained within IGEM/G/11 'Gas Industry Unsafe Situations Procedure' - formerly Gas Safe Register Technical Bulletin (TB) 001
- Where the installation has been proved to be tight and the smell of gas persists contact the National Gas Emergency Call Centre.
- Warn occupants and leave the building.

**WARNING:**

If any product of combustion are released :

- Follow a fumes investigation procedure in accordance to BS 7967:2015

**WARNING:**

This appliance's earth continuity is provided by link cables (green/ yellow) and specific holding screws. During any disassembly operations, make sure that the cables in question are reconnected; you MUST also reuse the original holding screws.

**WARNING:**

Risk of burns when emptying or touching the walls of the appliance

1.5. Water composition

For regions with very hard water (TH>24.5 Clark degrees), it is best to use a softener to prevent scaling problems in the heating element. Excessive scaling:

- Reduces device performance
- Can lead to corrosion of the heating element

Monitoring this is therefore important (the inspection hatch is provided for this purpose) and, if necessary, descale the appliance.

- The domestic water must meet the following criteria to guarantee the service life of the appliance:
- Chloride concentration less than 150 mg/L
- pH neutral (6.5 < pH < 8)
- Total chlorine concentration less than 1 mg/L

It is possible to disinfect the appliance by occasionally implementing what are called chlorine shocks within the limit of 50 mg/L of chlorine for between 4 to 6 hours. Exposure time should not exceed 24 hours at room temperature.

This disinfection can also be performed using hydrogen peroxide with a maximum concentration of 30% and an exposure time of less than 24 hours at room temperature.

The conductivity of the water must be greater than 100 µS/cm.

2. APPROVALS

2.1. Compliance with European Directives

- Low Voltage (2014/35/EU):

This product is intended for use only by competent persons.

Children should be supervised to ensure that they do not play with the appliance.

- Electromagnetic compatibility (2014/30/EU)

- Gas appliance (2016/426/UE)

- Eco-design (2009/125/EC):

In accordance with the Directive and the requirements of Regulation (EU) No 814/2013 of 2 August 2013, the technical parameters of water heaters with an output of 400 kW or less are provided in Appendix A.

- Energy efficiency labels (EU) 2017/1369 :

In application of the directive and according to the requirements of the EU regulation No. 812/2013 of 18 February 2013, the information on water heaters with a power of less than or equal to 70 kW is provided in appendix A of the installation manual.

- WEEE (2012/19/EU):

Waste Electrical and Electronic Equipment. See section 9. Standards and Regulations

Current Gas Safety (Installation and Use) Regulations or rules in force. The appliance is suitable only for installation in GB and IE and should be installed in accordance with the rules in force.

In GB, the installation must be carried out by a suitably qualified Gas Safe registered engineer or in IE by a competent person. It must be carried out in accordance with the relevant requirements of the: Gas Safety (Installation and Use) Regulations The appropriate Building Regulations either The Building Regulations, The Building Regulations (Scotland), Building Regulations (Northern Ireland). The Water Fittings Regulations or Water byelaws in Scotland. The Current I.E.T. Wiring Regulations.

Where no specific instructions are given, reference should be made to the relevant British Standard Code of Practice.

In IE, the installation must be carried out by a Competent Person and installed in accordance with the current edition of I.S.813 "Domestic Gas Installations" or I.S. 820 "Non-Domestic Gas Installations" as appropriate, the current Building Regulations and reference should be made to the current ETCI rules for electrical installation.

- The Building regulations.

Approved document G, Approved document L and Approved document P and Approved document J

Technical standard P3 Scotland

Building regulation P5 Northern Ireland

- British standards.

BS 5440 Flueing and ventilation for gas appliances of rated input not exceeding 70 kW net (1st, 2nd and 3rd family gases)

Part 1: Specification for installation of gas appliances to chimneys and for maintenance of chimneys.

Part 2: Specification for the installation and maintenance of ventilation provision for gas appliances.

BS 6644 Specification for the installation and maintenance of gas-fired hot water boilers of rated inputs between 70 kW (net) and 1.8 MW (net) (2nd and 3rd family gases)

BS 7671 Requirements of Electrical Installation IET wiring regulations 18th Edition

BS 6891 Specification for the installation and maintenance of low pressure gas installation pipework of up to 35 mm (R1¼) on premises

BS 5546 Specification for installation and maintenance of gas-fired water-heating appliances of rated input not exceeding 70 kW net

7074-2 Application, selection and installation of expansion vessels and ancillary equipment for sealed water systems. Code of practice for low and medium temperature hot water heating systems

BS 6880 1 Code of practice for low temperature hot water heating systems of output greater than 45 kW. Fundamental and design considerations

BS 6880 2 Code of practice for low temperature hot water heating systems of output greater than 45 kW. Selection of equipment

BS 6880 3 Code of practice for low temperature hot water heating systems of output greater than 45 kW. Installation, commissioning and maintenance

BS 6798 Code of practice for low temperature hot water heating systems of output greater than 45 kW. Installation, commissioning and maintenance

BS 6700 Design, installation, testing and maintenance of services supplying

water for domestic use within buildings and their curtilages.

Any installation must be in accordance with the relevant requirements of the Gas Safety Regulations, Building Regulations, I.E.E. Wiring Regulations and the Water Fitting Regulations (England and Wales) or Water Byelaws (Scotland). It should be read in accordance with the relevant recommendations of the following:

BS EN 12828 2012 Heating systems in buildings - Design for water-based heating systems.

BS EN 12831 Heating systems in buildings - Method for calculation of the design heat load

BS EN 14336 Heating systems in buildings - Installation and commissioning of water based heating systems

BS EN 806-1 Installations Inside Buildings Conveying Water for Human Consumption - Part 1: General

BS EN 806-2 Specification for installations inside buildings conveying water for human consumption - Part 2: Design

BS EN 806-3 Specifications for installations inside buildings conveying water for human consumption - Part 3: Pipe sizing

BS EN 806-4 Specifications for installations inside buildings conveying water for human consumption - Part 4: Installation

BS EN 806-5 Specifications for installations inside buildings conveying water for human consumption - Part 5: Operation and maintenance

BS 8558 : 2015 Guide to the design, installation, testing and maintenance of services supplying water for domestic use within buildings and their curtilages - complementary guidance to BS EN 806

BS 7593 : 2019 Code of practice for the preparation, commissioning and maintenance of domestic central heating and cooling water systems

- IGEN publications.

IGEM/UP/1B Tightness testing and direct purging of small Liquefied Petroleum Gas/Air, Natural Gas and Liquefied Petroleum Gas installations.

IGE/UP/1 Strength testing, tightness testing and direct purging of industrial and commercial gas installations

IGE/UP/1A Strength and tightness testing and direct purging of small low pressure industrial and commercial Natural Gas installations

IGE/UP/10 Installation of flued gas appliances in industrial and commercial premises

- Additional standards

Health and Safety at Work etc Act 1974

Electricity at Work Regulations 1989

The Water Supply (Water Fittings) Regulations 1999 - England & Wales

Water Supply (Water Fittings) Byelaws 2014 - Scotland

The Water Supply (Water Fittings) Regulations 2009 - Northern Ireland

- Fire Safety Regulations:

a) General requirements:

- Building regulations 2010 approved document B.

b) Special requirements for each type of establishment receiving the public (hospitals, shops, etc.).

2.2. Gas category

The EQMAX water heater has been factory-set to operate with group H natural gas (type G20) with a nominal supply pressure of 20 mbar. See chapter 4.8 for how to change the gas, and use a qualified professional



INFORMATION : Any work on a sealed component will lead to loss of the guarantee.

	Gas category
EQMAX SXX (20 to 30kW)	II2H3P
EQMAX MXX (35 to 60kW)	II2H3P
EQMAX LXX (70 to 120kW)	II2H3P

2.3. Gas supply pressures



INFORMATION : The pressures provided below must be taken at the inlet to the gas valve.




	Natural gas H G20	Gaz Propane G31
Nominal pressure (mbar)	20	37
Minimum pressure (mbar)	17	25
Maximum pressure (mbar)	25	45




INFORMATION : This DHW cylinder is compatible with natural gas G20 containing up to 20% hydrogen gas (H₂).

3. TECHNICAL SPECIFICATIONS

3.1. Dimensions






EQMAX SXX



EQMAX MXX


	MODELS									
	EQMAX SXX			EQMAX MXX			EQMAX LXX			
	20	25	30	35	50	60	70	80	100	120
1 Hot water outlet	Rp 1"1/2			Rp 1"1/2			Rp 1"1/2			
2 Secondary return	Rp 1"1/2			Rp 1"1/2			Rp 1"1/2			
3 Cold water inlet	Rp 1"1/2			Rp 1"1/2			Rp 1"1/2			
4 T&P valve (UK only)	Rp 1"			Rp 1" 1/4			Rp 1" 1/2			
5 Gas inlet	R 3/4"			R 3/4"			R 1"			
6 Air inlet	Ø 80			Ø 100			Ø 130			
7 Fume outlet	Ø 80			Ø 100			Ø 130			



REF	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
A	Overall Height	1802	1874	2028
B	Diameter	Ø 600	Ø 750	Ø 890
C	Height to cold water inlet	100	100	100
D	Height to inspection hatch	419	454	467
E	Height to secondary return	759	980	1129
F	Height to T&P valve connection	1193	1248	1373
G	Height to gas connection	1508	1580	1735
H	Height to hot water outlet	1514	1579	1748
I	Height to flue outlet	380	402	442
J	Height to air inlet	1691	1752	1871
K	Angle position of flue outlet	45°	45°	45°
L	Angle position of T&P valve fitting	13°	15°	70°
M	Angle position of gas connection	12.9°	20°	20°
N	Angle position of inspection hatch	45°	45°	38°
O	Angle position of HMI	90°	90°	90°
P	Height to lower anode fitting	NA	478	470
Q	Angle position of lower anode fitting	NA	80°	35°
R	Overall width with LPG conversion kit	NA	NA	1105
S	Angle position of gas connection with LPG conversion kit	NA	NA	20°
T	Width	699	884	1020
U	Height to condensate trap outlet	238	235	151

3.2. Boiler components

- | | |
|-------------------------------------|---------------------------------------|
| 1 Control unit | 8 Air inlet |
| 2 Ionisation electrode | 9 Air valve |
| 3 Ignition transformer | 10 Air pressure switch |
| 4 Sight glass | 11 Gas valve |
| 5 Upper powered anode | 12 Silicone tubes |
| 6 Complete display (user interface) | 13 Gas mixer |
| 7 Fan | 14 Ignition electrode (spark train) |
| | 15 Triplex sensor (behind HMI screen) |



Electrode details:






figure 2 - EQMAX components

- 16 Sample point
- 17 Lower powered anode
- 18 Smoke nozzle
- 19 Flue temperature sensor
- 20 NRV
- 21 Condensate removal siphon



3.3. Combustion at 15°C and 1013 mbar

3.3.1. Combustion G20

				EQMAX SXX		
				20 kW	25 kW	30 kW
Nominal power Pn	kW			21	26.3	31.5
Rated heat input Qn	kW			20	25	30
Min heat input Qmin	kW			6	6	6
Gas flow rate at Pn (15 °C)	m³/h			2.1	2.6	3.2
CO₂ & O₂ value range	%	G20	at Qmin	9,4 % < CO₂ < 9,8 % 3,4% < O₂ < 4,1 %		
			at Qmax	8,6 % < CO₂ < 9,0 % 4.9 % < O₂< 5.6 %		
Mass flow rate of the flue gas	g/s		Q _n Q _{min}	9.2 2.2	11.5 2.2	13.8 2.2
Temperature of the combustion products circuit	°C			100	100	100
Nominal operating temperature of the combustion products	°C			57	58	60
Exhaust outlet interior diameter	mm			80	80	80
Maximum allowable nozzle pressure (B23P)	Pa			110	170	200
Combustion air flow rate at Qn (15 °C)	m³/h			25	31	37
Nitrogen oxide emissions (NOx)	mg/kWh			29	29	29
Smoke removal and air inlet type classifications				B23 / B23P / C13 / C33		

				EQMAX MXX		
				35 kW	50 kW	60 kW
Nominal power Pn	kW			37	53	60
Rated heat input Qn	kW			35	50	56.6
Min heat input Qmin	kW			11.3	11.3	11.3
Gas flow rate at Pn (15 °C)	m³/h			3.7	5.3	6
CO₂ & O₂ value range	%	G20	at Qmin	9,0 % < CO₂ < 9,4 % 4,1% < O₂ < 4,9 %		
			at Qmax	8,2 % < CO₂ < 8,6 % 5,6 % < O₂ < 6,3 %		
Mass flow rate of the flue gas	g/s		Q _n Q _{min}	14.8 4.6	22.2 4.6	26.4 4.6
Temperature of the combustion products circuit	°C			100	100	100
Nominal operating temperature of the combustion products	°C			40.3	50.9	51.6
Exhaust outlet interior diameter	mm			100	100	100
Maximum allowable nozzle pressure (B23P)	Pa			130	200	200
Combustion air flow rate at Qn (15 °C)	m³/h			44	63	72
Nitrogen oxide emissions (NOx)	mg/kWh			32	32	32
Smoke removal and air inlet type classifications				B23 / B23P / C13 / C33		

				EQMAX LXX			
				70 kW	80 kW	100 kW	120 kW
Nominal power Pn	kW			73.4	84	105	126
Rated heat input Qn	kW			69.9	80	100	120
Min heat input Qmin	kW			24	24	24	24
Gas flow rate at Pn (15 °C)	m³/h			7.4	8.5	11	12.7
CO₂ & O₂ value range	%	G20	at Qmin	9,2 % < CO₂ < 9,6 % 3,8% < O₂ < 4,5 %			
			at Qmax	8,4 % < CO₂ < 8,8 % 5,2 % < O₂ < 5,9 %			
Mass flow rate of the flue gas	g/s		Q _n Q _{min}	29 9	33 9	44 9	52 9
Temperature of the combustion products circuit	°C			100	100	100	100
Nominal operating temperature of the combustion products	°C			56.8	58.8	59.8	59.3
Exhaust outlet interior diameter	mm			130	130	130	130
Maximum allowable nozzle pressure (B23P)	Pa			65	95	155	200
Combustion air flow rate at Qn (15 °C)	m³/h			88	101	126	152
Nitrogen oxide emissions (NOx)	mg/kWh			39	39	39	39
Smoke removal and air inlet type classifications				B23 / B23P / C13 / C33			

**INFORMATION :**

Compared with pure natural gas G20, a reduction in heat output of up to 7% is possible for a hydrogen (H₂) content of up to 20% in the gas mixture.

3.3.2. Combustion G31

			EQMAX SXX		
			20 kW	25 kW	30 kW
Nominal power Pn	kW		21	26.3	31.5
Rated heat input Qn	kW		20	25	30
Min heat input Qmin	kW		6	6	6
Gas flow rate at Pn (15 °C)	m³/h		0.8	1	1.2
CO₂ value range	%		at Qmin: 10.8 % < CO₂ < 11.2 % at Qmax: 10.4 % < CO₂ < 10.8 %		
Mass flow rate of the flue gas	kg/h	Q _n Q _{min}	21.6 7.2	31.7 7.2	38.2 7.2
Temperature of the combustion products circuit	°C		100	100	100
Nominal operating temperature of the combustion products	°C		37	53	59
Exhaust outlet interior diameter	mm		80	80	80
Maximum allowable nozzle pressure (B23P)	Pa		120	200	200
Combustion air flow rate at Qn (15 °C)	m³/h		24	30	36
Smoke removal and air inlet type classifications			B23 / B23P / C13/ C33		

			EQMAX MXX		
			35 kW	50 kW	60 kW
Nominal power Pn	kW		37	53	60
Rated heat input Qn	kW		35	50	56.6
Min heat input Qmin	kW		11.3	11.3	11.3
Gas flow rate at Pn (15 °C)	m³/h		1.4	2	2.4
CO₂ value range	%		at Qmin: 10.8 % < CO₂ < 11.2 % at Qmax: 10.4 % < CO₂ < 10.8 %		
Mass flow rate of the flue gas	kg/h	Q _n	42.8	63.0	76.7
		Q _{min}	14.4	14.4	14.4
Temperature of the combustion products circuit	°C		100	100	100
Nominal operating temperature of the combustion products	°C		37.8	48.7	50.8
Exhaust outlet interior diameter	mm		100	100	100
Maximum allowable nozzle pressure (B23P)	Pa		152	200	200
Combustion air flow rate at Qn (15 °C)	m³/h		42	60	68
Smoke removal and air inlet type classifications			B23 / B23P / C13 / C33		

		EQMAX LXX			
		70 kW	80 kW	100 kW	120 kW
Nominal power P _n	kW	73.4	84	105	126
Rated heat input Q _n	kW	69.9	80	100	120
Min heat input Q _{min}	kW	24	24	24	24
Gas flow rate at P _n (15 °C)	m ³ /h	2.7	3.1	4	4.7
CO ₂ value range	%	at Q _{min} : 10.8 % < CO ₂ < 11.2 % at Q _{max} : 10.4 % < CO ₂ < 10.8 %			
Mass flow rate of the flue gas	kg/h	Q _n	93.6	108.0	136.8
		Q _{min}	32.4	32.4	32.4
Temperature of the combustion products circuit	°C	100	100	100	100
Nominal operating temperature of the combustion products	°C	53.1	56.3	57.6	58.5
Exhaust outlet interior diameter	mm	130	130	130	130
Maximum allowable nozzle pressure (B23P)	Pa	52	70	127	200
Combustion air flow rate at Q _n (15 °C)	m ³ /h	85	97	121	145
Smoke removal and air inlet type classifications		B23 / B23P / C13 / C33			

3.4. Operating conditions

		EQMAX SXX	EQMAX MXX	EQMAX LXX
Max DHW temperature setting	°C	80	80	80
DHW safety temperature	°C	92	92	92
Max service pressure	hPa (bar)	7000 (7)	7000 (7)	7000 (7)
Water content	L	210	356	538
Weight without water	kg	96	142	240
Acoustic power at P_{max} (Lw) *	dB (A)	63.6	75.4	77.9
Acoustic pressure 1 m at P_{max} (Lp)	dB (A)	52	64	66
Installation premises temperature (min / max)	°C	5 / 40	5 / 40	5 / 40
Installation premises relative humidity		between 15% and 95%	between 15% and 95%	between 15% and 95%
Protection level		IP 21	IP 21	IP 21
Maximum installation altitude	m	2000	2000	2000

* The sound power level is a laboratory measurement of the emitted sound power but contrary to the noise level, it doesn't correspond to the perceived measurement.

3.5. Electrical connection

		EQMAX SXX			EQMAX MXX			EQMAX LXX			
		20	25	30	35	50	60	70	80	100	120
Electrical power supply	V	230 V AC (+10% -15%), 50Hz			230 V AC (+10% -15%), 50Hz			230 V AC (+10% -15%), 50Hz			
Electrical power consumed at Q_n (excluding accessory)	W	34	50	68	79	197	266	70	90	160	270
Electrical power consumption in standby mode	W	3.6	3.6	3.6	3.7	3.7	3.7	4.5	4.5	4.5	4.5
Maximum length of sensor cables	m	DHW storage tank sensor: 6m			DHW storage tank sensor: 6m			DHW storage tank sensor: 6m			
Terminal output power	V	230V AC (+10%, -15%)			230V AC (+10%, -15%)			230V AC (+10%, -15%)			
	A	From 5 mA to 1 A			From 5 mA to 1 A			From 5 mA to 1 A			
Fuses		T6.3H 250V x 2			T6.3H 250V x 2			T6.3H 250V x 2			

4. INSTALLATION

4.1. Ventilation


The appliance may only be installed in a room that complies with the requirements stated in national and local ventilation regulations.

BS.5440	Inst. and maintenance of flues and ventilation for gas appliances of rated input not exceeding 70kW net (1st, 2nd and 3rd family gases).
Part 2	Specification for installation and maintenance of ventilation for gas appliances
BS.6644 : 2011	Installation of gas fired hot water boilers of rated inputs between 70kW and 1.8MW (net) (2nd and 3rd family gases)
IGEM/UP/10	Installation of gas appliances in industrial and commercial premises

4.2. Unvented installation

Unvented installations require a number of mandatory safety devices to be installed onto the system to prevent the build up of excessive pressure within the supply system or the storage vessel.

A bespoke unvented kit is offered and will supply the mandatory safety devices required to comply with Part G3 of the Building Regulations as well as the Water Regulations. The components shown in the drawing below must be installed in this order on the cold mains supply :



INFORMATION:


The EQMAX water heater does not come with an integrated drain valve. A tee, reducing fitting and drain valve are provided within the unvented kit and must be fitted closest to the cold water inlet connection.

The following information is taken from Approved Document G3 of the Building Regulations and is provided to assist with the design and installation of the discharge pipework. However, the information is not exhaustive and reference should always be made to Approved Document G3 of the Building Regulations. The final decision regarding any arrangements rests with Building Control and it is recommended that their advice is sought if you have any concerns regarding this aspect of the installation.

The two safety valves will only discharge water under fault conditions. When operating normally water will not be discharged.

The tundish should be vertical, located in the same space as the unvented hot water storage system and be fitted as close as possible and within 600mm of the safety device e.g. the temperature relief valve.

The discharge pipe (D2) from the tundish should terminate in a safe place where there is no risk to persons in the vicinity of the discharge, be of metal and:



a) Be at least one pipe size larger than the nominal outlet size of the safety device unless its total equivalent hydraulic resistance exceeds that of a straight pipe 9m long i.e. discharge pipes between 9m and 18m equivalent resistance length should be at least two sizes larger than the nominal outlet size of the safety device, between 18 and 27m at least 3 sizes larger, and so on. Bends must be taken into account in calculating the flow resistance. Refer to the table and the worked example.

An alternative approach for sizing discharge pipes would be to follow BS EN 806-2:2005 Specification for design installation, testing and maintenance of services supplying water for domestic use within buildings and their curtilages.

b) Have a vertical section of pipe at least 300mm long, below the tundish before any elbows or bends in the pipe work.

c) Be installed with a continuous fall.

d) It is preferable for the discharge to be visible at both the tundish and the final point of discharge but where this is not possible or practically difficult there should be clear visibility at one or other of these locations.

Worked Example

The example below is for G1/2 temperature relief valve with a discharge pipe (D2) having 4 elbows and length of 7m from the tundish to the point of discharge.

From the table below:

Maximum resistance allowed for a straight length of 22mm copper discharge pipe (D2) from a G1/2 temperature relief valve is: 9m subtract the resistance for 4 x 22mm elbows at 0.8m each = 3.2m.

Therefore the maximum permitted length equates to: 5.8m.

5.8m is less than the actual length of 7m therefore calculate the next largest size.

Maximum resistance allowed for a straight length of 28mm pipe (D2) from a G1/2 temperature relief valve equates to: 14m.

As the actual length is 7m, a 28mm (D2) copper pipe will be satisfactory.

Sizing of copper discharge pipe 'D2' for a temperature relief valve with a G1/2 outlet size (as supplied)

Size of discharge pipework	Maximum length of straight pipe (no bends or elbows)	Deduct the figure below from the maximum length for each bend or elbow in the discharge pipe
22mm	Up to 9m	0.8m
28mm	Up to 18m	1m
35mm	Up to 27m	1.4m

Examples of acceptable discharge arrangements are:

1. Ideally below the fixed grating and above the water seal in a trapped gulley.
2. Downward discharges at a low level; i.e. up to 100mm above external surfaces such as car parks, hard standings, grassed areas etc are acceptable providing that where children play or otherwise come into contact with discharges, a wire cage or similar guard is positioned to prevent contact whilst maintaining visibility.
3. Discharges at a high level; e.g. into metal hopper and metal down pipe with the end of the discharge pipe clearly visible (tundish visible or not) or onto a roof capable of withstanding high temperature discharges of water and 3m from any plastic guttering systems that would collect such discharges.
4. Where a single common discharge pipe serves more than one system, it should be at least one pipe size larger than the largest individual discharge pipe (D2) to be connected.
5. If unvented hot water storage systems are installed where discharges form safety devices may not be apparent i.e. in dwellings occupied by blind, infirm or disabled people, consideration should be given to the installation of an electronically operated device to warn when discharge takes place.



WARNING:

RISK OF INJURY OR DEATH




The Temperature and Pressure Relief Valve must be fitted and should not be disconnected other than for replacement. The Temperature and Pressure Relief valve will open if the pressure or temperature within the tank exceeds the valve limit. The EQMAX water heaters are provided as standard with a 7 bar / 90°C T&P relief valve. If the valve is activated, it will remain open until the water has dropped below the unsafe temperature and pressure limit.

4.3. Vented installation

With a vented installation, excess pressure is taken up by the open cold water head tank. The level of the cold water head tank determines the maximum working pressure in the tank. The water heater must also be fitted with a vent pipe from the hot water pipe, which opens into the cold water head tank. Ideally, the vent pipe should discharge into a separate discharge channel/drain or otherwise to the open cold water head tank. The water heater should also be fitted with a stop valve on the hot water side. A Temperature and Pressure Relief Valve is only mandatory in unvented installations.

However, Ideal also strongly recommends the use of a Temperature and Pressure Relief Valve in vented installations.

4.4. Removing the cover panel



**figure 3 - Screw positions for cover
dismount**

1. Remove the 2 screws securing the cover
2. Remove the top cover
3. Unscrew the 2 retaining screws on each side of the display:
4. Remove the front screen.




figure 4 - Retracted screen

EQMAX SXX and MXX models have a moveable screen that can be hung from the front part of the EQMAX to facilitate access to the burner as well accessing the settings.

4.5. Installing the EQMAX

EQMAX must not be installed on an inflammable surface (wooden floor, inflammable floor covering, etc.).

Recommended distances relative to walls and ceiling:

Sufficient clearances must be provided to permit easy maintenance operations on the boilers. The minimum clearance required is 500 mm around the boiler and 175 mm above it.

These values cannot be substituted for the specific regulatory requirements.

The product must be levelled if required.



IMPORTANT:

The drilled holes on the base of the unit must not be used to mount adjustable feet

4.6. Flue installation connection

You must comply with the regulatory texts and rules of the art that apply in the country where the boiler will be installed, i.e.:

IGEM UP10, BS 6644 (when installed within a domestic environment), BS EN 806 and BS 8558 .

An exhaust temperature sensor guarantees the protection of the type B combustion product evacuation ducts. The temperature cannot be adjusted and is fixed at 100°C.

Any concentric system must be comprised of the manufacturers specified flue parts. Open flue systems (B23) must use the manufacturer specified air inlet basket.

It is not permitted to combine flue systems from different manufacturers.

EQMAX appliances are approved according to the gas category to be connected to:

- Open flue systems B23 and B23P
- Horizontal and vertical concentric systems C13 and C33

For room sealed flue systems, concentric flues from Ideal must be used.

Further information and installation instructions can be found within the Installation Manual for the Flue Starter Kits.



IMPORTANT:

The exhaust ducts must be correctly supported. Their weight must not rest on the EQMAX's smoke outlet or the air inlet

A range of bespoke flue starter kits are available to purchase from Ideal, in open flue (B23) and room sealed (C type) variants. For B23 systems it is strongly recommended to purchase and install these kits as these components have been designed to support the weight of the flue system without any stress being placed upon the air inlet or flue outlet. For C type flue systems, purchasing and installing these kits is a mandatory requirement to meet system approvals. Requirement to meet system approvals.

4.6.1. Connection to a B23 chimney

B23 type connection:

An appliance intended to be connected to a flue which evacuates the products of combustion to the outside of the room containing the boiler. The combustion air is drawn directly from the room. The fan is up stream of the combustion chamber.



IMPORTANT:

Check that the room where the boiler is to be installed has upper and lower ventilation ducts, that they comply with current regulations and are not obstructed.




figure 5 - B23 type connection

The size of the chimney pipes must be determined by taking account of combustion gas pressure on the water heater's output equal to 0 Pa (see table § 3.3).

The flue ducts must be made in a material resistant to the condensate that can form when the boiler is operating. These materials must also be capable of supporting flue gas temperatures up to 120°C. Horizontal duct runs must be avoided so as to limit condensate retention.

The heater is designed to be fired into a flue with a balanced draught condition (0Pa). If suction conditions exceed this it is permitted to install a suitable draught stabiliser, specialist advice from a flue specialist should be sought if required.

Check that the combustion gas is evacuated via the suitable and approved pipe flue pipe system.

EQMAX appliances are high performance water heaters with very low exhaust temperatures; consequently to retain a favourable draft the ducts must run upwards from the storage tank outlet.



WARNING:

If several water heaters are connected to one flue, check by calculation that the flue is not pressurised when all the boilers are operating at Q_n .



IMPORTANT:

The dimensions of the flues must be determined by the flue supplier.



IMPORTANT:

The storage unit's connection part must not be made to support the exhaust duct's weight.



IMPORTANT:

Installation of an air filter (ref. Ideal Kit for EQMAX SXX: 031303, EQMAX MXX: 031275, EQMAX LXX: 031305) is strongly recommended to protect the burner tube from clogging. This clogging can cause ignition errors (E133) or flame failure during operation (E128). Cleaning the tube is usually enough to resolve safety shut-downs.

4.6.2. Connection to a B23P chimney

B23P type connection:

Air from the installation premises, gas evacuation through the roof via a pressurised duct.



IMPORTANT:

Check that the boiler installation premises have high and low ventilation, that it conforms to current regulations and that it is not obstructed.



WARNING:

The combustion product extraction duct must be dimensioned by using the parameters set out in the table in chapter 3.3.

Depending on the actual configuration of the duct, a calculation is required to check that the pressures at the boiler outlet do not exceed the maximum allowable values (see table below).

Maximum allowable nozzle pressure (B23P) (Pa)	EQMAX SXX			EQMAX MXX			EQMAX LXX			
	20 kW	25 kW	30 kW	35 kW	50 kW	60 kW	70 kW	80 kW	100 kW	120 kW
G20	110	170	200	130	200	200	65	95	155	200
G31	120	200	200	152	200	200	52	70	127	200



IMPORTANT:

Installation of an air filter (ref. Ideal Kit for EQMAX SXX: 031303, EQMAX MXX: 031275, EQMAX LXX: 031305) is strongly recommended to protect the burner tube from clogging. This clogging can cause ignition errors (E133) or flame failure during operation (E128). Cleaning the tube is usually enough to resolve safety shut-downs.

Special case of a cascade installation:

In the case that storage tanks of different powers are connected, the most powerful models must be as close as possible to the chimney.

The EQMAX has an internal non-return exhaust valve which negates the fitting of same in shared flue systems.

Please ensure that any other connected appliances are B23P-approved.

4.6.3. Connection to a C13 or C33, suction pipe

C13 type connection:

A room sealed appliance designed for connection via ducts to a horizontal terminal, which admits fresh air to the burner and discharges the products of combustion to the outside through orifices which, in this case, are concentric. The fan is up stream of the combustion chamber.

C33 type connection:

A room sealed appliance designed for connection via ducts to a vertical terminal, which admits fresh air to the burner and discharges the products of combustion to the outside through orifices which, in this case, are concentric. The fan is up stream of the combustion chamber.



INFORMATION:

The length of the concentric ducts between the concentric adaptator and terminal (both not included) must not exceed 20m.
See table below equivalence




figure 6 - C13 type connection

	Ø 80-125	Ø 100-150	Ø 130-200
45° elbow	0.5m	0.5m	0.5m
90° elbow	1m	1m	1m





figure 7 - C33 type connection

4.6.4. Connection and draining of condensates



Removal to the drains, via a drain point, using a P.V.C tube (minimum diameter 32 mm) is mandatory because the condensates are acid and thus aggressive (pH between 3 and 5). Use a sufficient slope of minimum 3% to ensure correct flow of the condensates.


All pipework and fittings in the condensate drainage system **MUST** be compatible with condensate. Refer to either BS 6644:2011 or the Building Regulations for materials that should be used.



IMPORTANT:

Neutralise these condensates before removal according to the current regulations.

4.7. Hydraulic connection



The following must be fitted to the cold water pipe:

- an isolation valve,
- a drain valve.
- an anti-return flap
- a safety valve rated at 7 bar in compliance with standard NF P 52.001 and its system for evacuating directly to the sewer.

The following must be fitted to the hot water pipe:

- a pressure gauge (check that the maximum working pressure does not exceed 7 bar).

REMINDER: In accordance with the DTU, the installer must ensure that an automatic drain valve is fitted at the high points of the installation.



WARNING:

The product is not fitted with a drain tap. A drain valve must be installed on the cold water inlet to allow the product to be drained.



WARNING:

The components used to seal the connections must be WRAS or equivalent certified products.



IMPORTANT:

In operating conditions where the hot water outlet temperature is over 60°C, the installation must comply with the applicable regulations. A safety mixer tap may be required to obtain an acceptable temperature at the point of use.



IMPORTANT:

The DHW temperature must always remain below the maximum operating temperature of the domestic water pipes (especially when using PER or PVC pressure pipes) and the components of the hydraulic circuit.

4.8. Gas change G20-G31

This EQMAX has been factory-set to work with group H (type G20) natural gas with a supply pressure of 20 mbar.



IMPORTANT:

Any operations involving changing the type of gas used must be performed by a qualified professional.

The valve must be adjusted on the water heater while operating at the maximum and minimum power. To do this, use the operation mode "Manual power adjustment" (see the instructions for the NAVISTEM H3100 boiler controller) which enables the user to switch straight to the minimum or maximum setpoint value (i.e. to zero or full power).



IMPORTANT:

The settings have been approved for the gas supply pressures at the valve inlet (measured on the pressure meter before the gas valve and with the burner working) in the tables in the following chapters.



IMPORTANT:

The setting mechanism must be sealed once the operation is complete. All damaged seals must be replaced.

4.8.1. Operation with hydrogen (H₂)



DANGER :

If the DHW cylinder is operated with natural gas containing up to 20% hydrogen (H₂), the factory setting of the G20 gas valve must not be altered.

If this setting is not respected, there is a risk of damage to the installation (e.g. overheating, premature ageing, etc.) and serious injury (e.g. carbon monoxide CO poisoning).

Check the O₂ setting (see §.5.1.)



INFORMATION :

If the DHW cylinder is operated with natural gas containing up to 20% hydrogen gas (H₂), combustion hygiene in the flue gas is checked exclusively on the basis of the O₂ content (%).

In the event of incorrect adjustment, and after checking all other possible causes, please contact the after-sales service.

4.8.2. Change from G20 to G31

Refer to section 4.8.1.3 for instructions on how to implement the settings changes as the last step of this process

4.8.2.1. Installing the propane injector EQMAX SXX models



IMPORTANT:

ONLY on 20 to 30kW storage tanks
031256 - EQMAX S20, 031257 - EQMAX S25, 031258 - EQMAX S30



IMPORTANT:

Complete the modification before connecting the gas line

Change the type of gas by installing an injector at the gas valve outlet.
Remove the fixing clip (4) downstream of the valve.
Remove the versilic tubes from the air hose.
Unscrew the air hose collars and remove it.
Unscrew the fan screws (6).
Remove the fan + venturi sub-assembly.
Position the injector (7) in the valve (see figure).
Replace the gas valve O-ring (3) with the additional supplied seal.
Replace the fan seal (5)
Install the assembly.




figure 8 - installing the propane injector

4.8.2.2. Change from G20 to G31 for EQMAX MXX



IMPORTANT:

ONLY for boilers from 35 to 60 kW.



IMPORTANT:

Only gas valve re-adjustments is required for models EQMAX MXX, see table page 37.

4.8.2.3. Installing the propane injector EQMAX LXX models




figure 9 - installing the propane injector



IMPORTANT:

ONLY on 70 to 120kW storage tanks

031262 - EQMAX L70, 031263 - EQMAX L80, 031264 - EQMAX L100,
031265 - EQMAX L120



IMPORTANT:

Always replace seals after disassembly.

IMPERATIVELY check the different seals after assembly.



IMPORTANT:

It is essential to use the 235594 SG70-120 LPG Conversion Kit supplied as an option by Ideal. Refer to the kit instructions for installing specific components and before modifying the LMS settings, adjusting the gas valve, and adjusting the regulator.

4.8.2.4. Changing the ignition, pre-ventilation, minimum and maximum speeds

Put the EQMAX on standby.



If necessary, press the ESC button to return to the main screen.


Open the Settings / Safety unit menu at specialist level.

Adjust the pre-ventilation speed (9504), ignition speed (9512), minimum speed (9524) and maximum speed (9529) settings:


Models	Gas	9504	9512	9524	9529
S20	G20	5450	5840	2200	6030
	G31	5450	5700	2100	5700
S25	G20	5450	5840	2200	7390
	G31	5450	5700	2100	6970
S30	G20	5450	5840	2200	8500
	G31	5450	5700	2100	7850
M35	G20	5000	3870	2250	6250
	G31	5000	3800	2200	5630
M50	G20	5000	3870	2250	8890
	G31	5000	3800	2200	7880
M60	G20	5000	3870	2250	9800
	G31	5000	3800	2200	8800
L70	G20	3200	3300	1700	3810
	G31	3200	3470	1620	3470
L80	G20	3200	3300	1700	4330
	G31	3200	3470	1620	3740
L100	G20	3200	3300	1700	5270
	G31	3200	3470	1620	4600
L120	G20	3200	3300	1700	6400
	G31	3200	3470	1620	5700

4.8.2.5. Adjustment of the gas valve


- Before starting the burner, on the gas valve, preset the gas flow rate, using the gas flow rate adjustment screw R1, to the appropriate value given in the following table for settings
- Start the burner at maximum power.
- Using a combustion analyser, measure the CO₂ ratio in the exhaust gases: on the exhaust outlet nozzle, remove the plug from the opening and insert the CO₂ measurement sensor into the centre of the flow in the exhaust duct.
- Check the CO₂ value at maximum power Q_{max} and, if necessary, adjust the gas flow screw R1 of the valve in order to obtain the CO₂ values in the following table for settings
- Change to minimum power Q_{min} and check that the CO₂ value is within the range in the table below. If necessary, use the setting adjustment screw R2
- If the setting is adjusted at minimum power, go back to maximum power Q_{max} and recheck the CO₂ value. Repeat the operation until both values comply with the following table for settings.
- Return to the standard operating mode.



**figure 10 - EQMAX
SXX setting**



**figure 11 - EQMAX
MXX setting**



**figure 12 - EQMAX
LXX setting**

After changing the type of gas:

- Check the sealing of the gas line.
- Stick the G31 data plate label provided in place of the original label (G20)

Model	Gas	Pre-setting the gas flow adjustment screw R1 and the R2 / G20 regulator setpoint adjusting screw	CO ₂ Pmax	CO ₂ indicative Pmin
S20	G20	Screw R1 all the way Unscrew R1 for 3 1/4 turns, adjust R2	10.4% < CO₂ < 10.8% 4.5% < O₂ < 5.1%	10.8% < CO₂ < 11.2% 3.9% < O₂ < 4.5%
	G31	(Valve set G20) Screw R1 for 1/2 turn, adjust R2		
S25	G20	Screw R1 all the way Unscrew R1 for 3 1/4 turns, adjust R2		
	G31	(Valve set G20) Screw R1 for 1/2 turn, adjust R2		
S30	G20	Screw R1 all the way Unscrew R1 for 3 1/4 turns, adjust R2		
	G31	(Valve set G20) Screw R1 for 1/2 turn, adjust R2		
M35	G20	Screw R1 all the way Unscrew R1 for 4 1/2 turns, adjust R2		
	G31	(Valve set G20) Screw R1 for 1 turn, adjust R2		
M50	G20	Screw R1 all the way Unscrew R1 for 4 1/2 turns, adjust R2		
	G31	(Valve set G20) Screw R1 for 1 turn, adjust R2		
M60	G20	Screw R1 all the way Unscrew R1 for 4 1/2 turns, adjust R2		
	G31	(Valve set G20) Screw R1 for 1 turn, adjust R2		
L70	G20	Screw R1 all the way Unscrew R1 for 2 1/2 turns, adjust R2		
	G31	(Valve set G20) Unscrew R1 for 1 turn, adjust R2		
L80	G20	Screw R1 all the way Unscrew R1 for 2 1/2 turns, adjust R2		
	G31	(Valve set G20) Unscrew R1 for 1 turn, adjust R2		
L100	G20	Screw R1 all the way Unscrew R1 for 2 1/2 turns, adjust R2		
	G31	(Valve set G20) Unscrew R1 for 1 turn, adjust R2		
L120	G20	Screw R1 all the way Unscrew R1 for 2 1/2 turns, adjust R2		
	G31	(Valve set G20) Unscrew R1 for 1 turn, adjust R2		

4.9. Gas connection

Before installing the boiler, clean the interior of the gas line, which must be free of metal particles and welding debris. This will lengthen the lifespan of the product. The gas valve is fitted with an integrated filter (125µm), but this is not able to retain all the impurities contained in the gas and in the mains pipes. To avoid any malfunction of the gas valve, we advise the fitting of a suitable filter to the storage tank gas supply (50µm).

Before starting up for the first time, check that the pressure of the natural gas supply corresponds to the nominal boiler pressure, as marked on the rating plate.

Before feeding gas to the installation, ensure that the different connections are correctly made and gas tight.

A suitable isolation gas valve must be installed upstream of the final connection to the appliance.

A suitable fitting such as a union connector must be installed between the isolating valve and the gas supply connection to provide safe disconnection and allow for removal of the gas valve.

The value upstream of the gas valve must be within the limits shown in the table in chapter § 2.2, page 11.

**WARNING:**

**The gas line must not be subject to any mechanical stress (risk of loss of gas tightness of the gas valve).
Check that the gas supply corresponds to the nominal boiler pressure and gas category, as marked on the rating plate.**

**WARNING:**

If the storage tank is operated with natural gas containing up to 20% hydrogen (H₂), refer specifically to section 4.5.2, page 30.

4.10. Electrical connection / Wiring diagram

**WARNING:**

Ensure that the general electrical power supply has been cut off before starting any repair work.

**WARNING:**

You must respect the live (L) - neutral (N) polarity when making electrical connections.


**CAUTION:**

**It is mandatory to connect this boiler correctly to earth and to comply with the national standards which apply in the country for low-voltage electrical installations.
Provide a two-pole circuit breaker upstream of the boiler (distance between contacts: 3.5 mm minimum).
Fitting the electrical installation with a 30 mA differential protective device is strongly advised.**

**WARNING:**

The protective earth conductor must be longer than the phase and neutral conductors.

4.10.1. Cable ways



4.10.2. Characteristics of the electrical power supply

The electrical connections will only be made when all of the other assembly operations (attachment, assembly, etc.) have been carried out on the boiler.

The electrical installation must comply with CE standards for electrical connection, and in particular, the earth connection.

This appliance is designed to operate under a nominal voltage of 230 V +10% / -15%, 50 Hz.

Ensure that the following rules are observed when connecting to avoid degrading the measurement of the ionisation current:

- In single phase: it is essential to respect the phase – neutral polarity

If you are not equipped to measure the phase shift, wire the control box's power supply in both configurations then in both cases check the ionization current by going to the "generator diagnostics" menu at parameter 8329 .


4.10.3. Cable sections

The following cable sections are given for information purposes only and do not exempt the installer from checking that they meet requirements and comply with standards in force.

If a cable is damaged, it must be replaced by the manufacturer, its after-sales service or any suitably qualified person, in order to avoid any danger.

Cable	Terminal blocks	Copper conductor section
Power	Power supply	3 x 1.5 mm ²
	QX1 and QX2	3 x 1.5 mm ²
Signals	B3, BX2, BX3, H1, OT	2 x 0.5 mm ²
	Navipass Modbus bus	3 x 0.5 mm ²

4.10.4. Fuses



The EQMAX is equipped with 2 identical T6.3H 250V fuses located to the right of the connection terminals. These fuses ensure that all the boards installed in the panel are protected.

4.10.5. Electric connections to terminals





figure 13 - Signal terminals



Fixed terminal:
Do not disconnect
(power supply)




figure 14 - Power and power supply terminals



5. START-UP

5.1. Filling the boiler

- Open a tap (air vent and end-of-fill check).
- Check that the drain valve is closed.
- Open the cold water supply valve.
- Close the tap opened previously once the storage tank has been completely filled and vented.
- Check the water pressure, which must be less than 7 bar, and the safety valve, which must not leak.

5.2. Starting-up



WARNING:

Never operate the water heater if it is not filled with water.

1. Switch on the main circuit breaker.
2. Create a request for heat via the comfort mode using the customer interface (see the NAVISTEM H3100 manual).
3. After starting the burner, check the gas tightness of the gas line connections using a foaming product. Check the combustion hygiene using a smoke analyser via a sampling plug on the fume nozzle.

The procedure for checking combustion hygiene is detailed in section § 7.5, page 47

In the event of poor combustion hygiene, it may be necessary to readjust the gas valve as described in section § 7.6, page 48.

4. Adjust the DHW setpoint (settings 1610 and 1612 - refer to the table summarising customer parameters at the end of this manual).

The range of CO₂ or O₂ values to be respected depends on the operating gas: refer to the tables in section § 3.3, page 16.



INFORMATION :

If the accumulator is operated with natural gas containing up to 20% hydrogen (H₂), combustion hygiene in the flue gases is checked exclusively on the basis of the O₂ content (%).

6. CHECKS AFTER COMMISSIONING

6.1. Condensate removal

Check that the removal of condensates is not obstructed, on both the boiler side and the pipe side.

6.2. Gas supply

Check that the gas pipe diameter is correctly sized:

It is necessary to stop all the gas appliances from the boiler room together abruptly using the boiler room main circuit breaker to check that the gas pressure regulator safety device is not triggered.

If this is triggered, the gas pipe is undersized. After this operation, reengage the circuit breaker. The storage tanks must start automatically, if not, consult the supplier of the gas pressure regulator.

7. MAINTENANCE OPERATIONS

The common maintenance programme features 2 types of work :

- Maintenance which is carried out every year
- In-depth maintenance which is carried out every 3 years.

The table below contains the actions to be carried out according to the type of maintenance operation.

These operations must be carried out by a qualified professional in all cases.

A specific check of the safety valve by operating it and checking the water flow should be carried out at least once a month.



WARNING:

This storage tank's earth continuity is provided by link cables (green/yellow) and specific holding screws. During any disassembly operations, make sure that the cables in question are reconnected; you **MUST** also reuse the original holding screws.

Before performing the following operations:

- Switch off the main circuit breaker.
- Close the gas supply isolation valve.

N° of paragraph to consult		Servicing	
		every year	every 3 years
7.1	Descaling and cleaning of the storage tank	X	
7.2	Inspection of ignition and ionization electrodes	X	
7.3	Cleaning siphons for condensate evacuation	X	
7.4	Verification of tightness on combustion circuit	X	
7.5	Verification of combustion quality	X	
7.6	Checking the gas valve setting	X	
7.7	Checking the condition of the gas manifold coating Burner cleaning and sealing gaskets exchange Checking the evacuation in the by-pass		X

7.1. Descaling and cleaning of the storage tank

Emptying the water heater

- Close the cold water inlet tap.
- Connect the drain valve (see § 4.4) to the drain with a suitable hose,
- Open a tap.
- Open the drain valve



WARNING:

The water evacuated may be very hot.

An access panel on the front of the boiler permits access and cleaning of the bottom of the boiler using an industrial vacuum cleaner.

Each time the access panel is opened, the gasket must be changed.


The frequency of the descaling depends in the conditions of use of the storage tank, in particular the consumption, hardness and temperature of the stored water.. Storing the water at a temperature of 60°C or less will reduce the precipitation of limescale.



WARNING:

ONLY use products that are suitable and compatible with stainless steel and which do not present a health risk (WRAS or equivalent compatibility).

7.2. Checking the ignition and ionisation electrodes



Removing the electrodes

Electrically disconnect the electrodes

- the ionisation electrode at the connection
- the ignition electrode at the ignition transformer and ground connector

Unscrew the 2 M4 Torx screws holding the electrode to be removed.

If necessary and if there is major oxidation, clean the electrodes by rubbing them with an emery cloth.

figure 16 - Electrode location




figure 17 - Spacing

Check the spacing between the ignition electrodes (see figure opposite). It must be between 2.5 and 3.5 mm. If this is not the case, the electrode must be replaced.




figure 18 - Geometry

Check the ignition electrode fold geometry. If there is over ± 0.8 mm deformation, the electrode must be replaced.

Put back the electrode block(s). Block attachment screw tightening torque = 2.5 N.m Electrically reconnect the electrodes and the earth wire

7.3. Cleaning the condensate evacuation pipe




figure 19 - Siphon

Check the siphon and clean it if necessary. The siphon is underneath the fume nozzle.

To do so:

- Free the siphon by pulling it downwards.
- Clean it with water.
- Replace the siphon after checking that the floater (ball) is present and can move freely. Also check that the seal has not been damaged.

7.4. Checking the combustion circuit seal




figure 20 - Combustion leaks

Check for leaks with a foaming product. The areas to be checked are shown in the figure opposite. The check should be carried out when the appliance is cold (water heater turned off) but with the fan at maximum speed (obtained by disconnecting the PWM signal connector - see electrical diagram).

If you detect any leaks, you must replace the seal with the adapted kit.

We recommend replacing the seals each time it is opened.

7.5. Checking the combustion quality




figure 21 - Sampling plug

This check is carried out with a calibrated combustion kit. To do so, insert the measurement rod into the fume nozzle (see figure opposite).

The water heater setpoint must be equal to or greater than 65°C.



IMPORTANT:

Do not forget to put the cap back on the sampling plug opening after the measurement.

The CO₂ or O₂ content measured under these conditions must be within the range of values imposed according to the operating gas: refer to the tables in section § 3.3, page 16.

If this is not the case, you must readjust the gas valve (see next §).

Following this check, you must take a "gas start" flow rate measurement. This measurement is used to check the dirt build-up on the combustion circuit.

The "gas start" must be made for a period over 3 minutes to obtain a satisfactory level of accuracy.

If the gas flow rate is 20% lower in relation to the value indicated in the table in paragraph § 3.3, you must clean the burner (see § 7.7).



ATTENTION :

When operating the G31 propane accumulator, refer to the specific table for this gas in section § 3.3.2, page 19.



INFORMATION :

If the accumulator is operated with natural gas containing up to 20% hydrogen (H₂), combustion hygiene in the flue gases is checked exclusively on the basis of the O₂ content (%).

7.6. Checking the gas valve setting

This EQMAX storage tank has been adjusted in the factory to work with group H (type G20) natural gas with a supply pressure of 20 mbar.



IMPORTANT:

Any operations involving adjusting the gas valve must be performed by a qualified Gas Safe engineer or in IE by a competent person.

The valve must be adjusted on the boiler operating at the maximum power and the minimum power levels. Valve adjustment must be done in "Manual power setting mode" (see the instructions for the NAVISTEM H3100 boiler controller) which allows a direct switch to maximum power or minimum power (0% or 100%).

Start the burner at maximum power.

Using a combustion analyser, measure the CO₂ or O₂ level in the flue gas at the smoke nozzle..

Check the CO₂ or O₂ value at maximum power and, if necessary, adjust the gas flow screw of the valve in order to obtain the CO₂ or O₂ values that correspond to the model (see following table).

Change to minimum power Qmin and check that the CO₂ or O₂ value is within the range in the table below. If necessary, adjust the Offset regulator.

If the setting is adjusted to minimum power, go back to maximum power and check the CO₂ or O₂ value again. Repeat the operation until two compliant values are obtained.

Return to the standard operating mode.





figure 22 - Gas valve

		G20	G31
EQMAX SXX	20 kW	AT QMIN: 9,4 % < CO ₂ < 9,8 % 3,4% < O ₂ < 4,1%	AT QMIN: 10.8% < CO ₂ < 11.2% 3.9% < O ₂ < 4.5%
	25 kW	AT QMAX: 8,6 % < CO ₂ < 9,0 %	
	30 kW	4.9% < O ₂ < 5.6%	
EQMAX MXX	35 kW	AT QMIN: 9,0 % < CO ₂ < 9,4 % 4.1% < O ₂ < 4.9%	AT QMAX: 10.4% < CO ₂ < 10.8% 4.5% < O ₂ < 5.1%
	50 kW	AT QMAX: 8,2 % < CO ₂ < 8,6 %	
	60 kW	5.6% < O ₂ < 6.3%	
EQMAX LXX	69.9 kW	AT QMIN: 9,2 % < CO ₂ < 9,6 %	
	80 kW	3.8% < O ₂ < 4.5%	
	100 kW	AT QMAX: 8,4 % < CO ₂ < 8,8 %	
	120 kW	5.2 % < O ₂ < 5.9%	

7.7. Cleaning the burner and the evacuation in the by-pass and changing the seals



7.7.1. Cleaning the burner

Before beginning any type of burner zone dismantling, it is essential that you obtain the after-sales service kit for changing burner seals that is suitable for your appliance. (kit 555573 or 555574)

IMPORTANT: Any seal that is dismantled must be replaced.

Refer to the instructions for the burner seal kit(s) / burner pipe / complete burner etc. for disassembling and reassembling the burner elements for maintenance operations.

**IMPORTANT:**

When extracting the burner tube, avoid rubbing its "metal covering" against the flange.

Cleaning the burner tube:

- Use a vacuum cleaner to clean the whole "metal covering" surface.
- Check the condition of the gas manifold coating.


**CAUTION:****When refitting:**

- Always replace the gasket under the burner manifold.
- do not forget to connect the air transfer pipe to the "-" connection point of the air pressure switch.

**IMPORTANT:**

The burner seal must be replaced every 3 years

Please note that the size of the burner is different depending on the model.



7.7.2. The by-pass




figure 23 - By-pass

On the EQMAX MXX and EQMAX LXX models, are equipped with a By Pass tube allowing the evacuation of condensate formed in the fireplace.

Control the non-clogging of it by controlling the evacuation of water from the bottom of the hearth.

For EQMAX MXX models, this is done by gaining access through the yellow cap after the siphon has been moved.

For EQMAX LXX models, the by-pass can be accessed by removing the rear siphon hose.

8. HYDRAULIC DIAGRAMS AND CONFIGURATIONS

8.1. Symbols used in the diagrams

Symbol	Function
	Isolation valve open
	Motorised 2-channel valve
	Fixed flow pump
	Temperature sensor
	Variable flow pump
	Y Strainer
	Cut-off valve with bleed tap



Symbol	Function
	Balancing valve
	Bleed valve
	Outdoor sensor
	No return valve
	Security Group
	Safety valve
	Mixer tap

8.2. List of diagrams

EQMAX ONLY	53
<i>EQMAX with or without de-stratification pump for anti-legionella function</i>	
EQMAX + TANK(S) IN SEMI-ACCUMULATED	56
<i>EQMAX with volume mixing or tank load pump</i>	
EQMAX + TANK(S) IN SEMI-ACCUMULATED	60
<i>EQMAX with volume mixing or tank load pump</i>	
EQMAX + TANK(S) SEMI-INSTANT.....	66
<i>EQMAX and tank(s) with volume mixing or tank load pump</i>	
EQMAX CASCADE WITHOUT TANK(S).....	70
<i>Hydraulic cascade of 2 EQMAXs</i>	
EQMAX CASCADE WITH TANK(S)	74
<i>EQMAX cascade with tank, with or without manual bypass of the safety mixing tap for the anti-legionella cycle</i>	

EQMAX ONLY*EQMAX with or without de-stratification pump for anti-legionella function*Diagrams
EQMAX100
EQMAX102

page 1 / 3

A. HYDRAULIC DIAGRAM**figure 24 - EQMAX100 diagram without de-stratification pump****figure 25 - EQMAX102 diagram with de-stratification pump**

B. OPTIONAL ACCESSORIES REQUIRED

EQMAX100 diagram: No accessories.

EQMAX102 diagram:

	Quantity	Appliance reference	Order No.
De-stratification pump	1	EQMAX Re-circulation pump	236166

C. OPERATING DESCRIPTION

Version EQMAX 100 diagram:

The EQMAX is autonomous, the DHW setpoint is adjusted based on the desired flow temperature.



IMPORTANT:

Check that the loop flow rate and temperatures comply with the regulations; if necessary, adjust the loop circulator adjustment valve and/or the mixing tap setpoint.

Version EQMAX 102 diagram:


The EQMAX is autonomous, the DHW setpoint is adjusted based on the desired flow temperature. The optional recirculation pump can homogenise the water contained in the EQMAX to give enhanced temperature control and be used in the control of legionellosis.



IMPORTANT:

Check that the loop flow rate and temperatures comply with the regulations; if necessary, adjust the loop circulator adjustment valve and/or the mixing tap setpoint. You will notice that there is a bypass at the mixing tap terminals that can increase the temperature of the distribution loop during anti-legionella cycles; remember to close this bypass after the anti-legionella cycle.

D. CUSTOMER'S ELECTRICAL CONNECTION



Diagrams: EQMAX100, EQMAX102

page 3 / 3

E. SPECIFIC START-UP PROCEDURE

☞ Correctly install and connect the electrical connections.

☞ Make the settings below in "specialist" mode

 Short press

 Press 3 seconds

End user

Commissioning

Specialist

OEM

Line No.**Value**

• Time and date menu

Set time

Hour / minute (1)

HH.MM

Set the date

Day / month (2)

DD.MM

Set the year

Year (3)

YYYY

• Configuration menu

Configure just the EQMAX
(without additional tank)

DHW tank heating gas (5741)

Stop

Configure the alarm output

Relay output QX1 (5890)

Alarm output K10

Configure the de-stratification pump
output (EQMAX120 diagram)

Relay output QX2 (5891)

Destratifier pump DHW
Q35

• Heating gas menu DHW

Adjust the comfort setpoint

Comfort setting temperature (1610)

---°C

DHW release request

Release (1620)

24/24

EQMAX102 diagram: Setting the anti-legionella cycle (if desired)

Activate the anti-legionella function

Anti-legionella function (1640)

stop / periodic / fixed day
of the weekChoice of repetition. From daily to every
7 days. 1640 = periodic

Function anti-legionella periodical (1641)

1 to 7 days

Choice of the day of the week
if 1640=fixed weekday

Function anti-legionella day week (1642)

Monday ... Sunday

Anti-legionella launch time

Anti-legionella function time (1644)

00:00

Heating T° setpoint for anti-legionella
function

Anti-legionella setpoint (1645)

as needed (°C)

Anti-legionella T° holding time

Anti-legionella function duration (1646)

as needed (min)

• DHW tank menu

Adjust burner request

Outlet setpoint T° over-value (5020)


-3 °C

DHW restart hysteresis



Differential (5024)

5 °C

- Switch the DHW mode to permanent comfort
(as per parameter 1620)



Refer to the "§Electrical validation" chapter for the regulator input/output tests

EQMAX + TANK(S) IN SEMI-ACCUMULATED
*EQMAX with volume mixing or tank load pump*Diagrams
EQMAX120
EQMAX121
page 1 / 4**A. HYDRAULIC DIAGRAM***figure 26 - EQMAX120 diagram**figure 27 - EQMAX121 diagram*

Diagrams: EQMAX120, EQMAX121

page 2 / 4

B. OPTIONAL ACCESSORIES REQUIRED

	Quantity	Appliance reference	Order No.
Insertion water temp sensor	1	QAZ 36	563605609

C. OPERATING DESCRIPTION

The EQMAX is coupled to 1 or 2 DHW tanks, the customer regulates the DHW setpoint he wishes to obtain at the product outlet, which will be the same setpoint for the tank(s).

A pump is installed between the tank and the EQMAX that can reactivate the tank(s) loading when the water they contained is lower than the setpoint minus the recovery hysteresis.

**IMPORTANT:**

When you are in DHW comfort mode (2 cursor on the HMI) the DHW tank loading pump operates permanently, the pump restarts in reduced mode (1 cursor on the HMI) when the temperature in the tank is not satisfactory.

You can choose to operate in permanent comfort mode (2 cursors on the HMI), permanent reduced mode (1 cursor on the HMI), or a timer program to alternate comfort and reduced modes (2 cursors on the HMI + timer program).

This pump operates during anti-legionella cycles to obtain a uniform water temperature in the storage tank.

A timer program can be used to perform loading at either the comfort DHW setpoint or at the reduced DHW setpoint.

**IMPORTANT:**

Check that the loop flow rate and temperatures comply with the regulations; if necessary, adjust the loop circulator adjustment valve and/or the mixing tap setpoint.

In principle, the circulator between the tank and the EQMAX is dimensioned to ensure a flow rate equal to $P / (1.16 \times \Delta T)$

- with P being the nominal power of the EQMAX (in kW) and

- ΔT = setpoint T – cold water T considering the temperature of cold water in summer.

However, it is imperative that this flow rate is higher than the loop return flow rate in the tank, once you are sure of compliance with distribution loop regulations.

It should be remembered that the power of the EQMAX must be determined on the basis of DHW consumption but also taking into account the heat losses of the distribution loop.


For example, for a cold water temperature of 18°C in summer, a DHW set point at 62°C on a the EQMAX M35.

Nominal power = 35kW

$\Delta T = 62 - 18 = 44^\circ\text{C}$

Circulator flow = $35 / (1.16 \times 44) = 0.69\text{m}^3/\text{h}$.

D. CUSTOMER'S ELECTRICAL CONNECTION



E. SPECIFIC START-UP PROCEDURE

- ☞ Correctly install and connect the electrical connections.
- ☞ Make the settings below in "specialist" mode

Short press

Press 3 seconds



End user Commissioning **Specialist** OEM

	Line No.	Value
• Time and date menu		
Set time	Hour / minute (1)	HH.MM
Set the date	Day / month (2)	DD.MM
Set the year	Year (3)	YYYY
• Configuration menu		
Configure EQMAX with an additional tank	DHW tank heating gas (5741)	Start
Configure the alarm output	Relay output QX1 (5890)	Alarm output K10
Configure the DHW tank pump output	Relay output QX2 (5891)	DHW pump Q3
• Heating gas menu DHW		
Adjust the comfort setpoint	Comfort setting temperature (1610)	---°C
Adjust the reduced setting	Reduced setpoint temperature (1612)	---°C

Diagrams: EQMAX120, EQMAX121

page 4 / 4

DHW release request

Release (1620) | 24/24

Setting the anti-legionella cycle (if desired)

Activate the anti-legionella function

Anti-legionella function (1640)

stop / periodic / fixed day
of the weekChoice of repetition. From daily to every
7 days. 1640 = periodic

Function anti-legionella periodical (1641)

1 to 7 days

Choice of the day of the week
if 1640=fixed weekday

Function anti-legionella day week (1642)

Monday ... Sunday

Anti-legionella launch time

Anti-legionella function time (1644)

00:00

Heating T° setpoint for anti-legionella
function

Anti-legionella setpoint (1645)

as needed (°C)

Anti-legionella T° holding time

Anti-legionella function duration (1646)

as needed (min)

• DHW tank menu

Adjust burner request

Outlet setpoint T° over-value (5020)


+4 °C

DHW restart hysteresis

Differential (5024)


5 °C

- Switch the DHW mode to permanent comfort (as per parameter 1620)



OR

- Switch the DHW regime to permanent reduced



If you want to lower the DHW setpoint (reduced setpoint) for a specific time range, use the following settings

• Heating gas menu DHW

DHW release request

Line No. Value

Release (1620)

Timer programme
4/DHW

• Timer program menu 4/DHW

Choose the programming range

Preselection (560)

e.g.: Monday-Sunday

Set the start of the comfort setpoint range

1st phase ON (561)


e.g.: 06:00 h

Set the end of the comfort setpoint range

1st phase Off (562)

e.g.: 22:00 h

- Switch the DHW mode to permanent comfort (as per parameter 1620)



Refer to the “§Electrical validation” chapter for the regulator input/output tests


EQMAX + TANK(S) IN SEMI-ACCUMULATED
*EQMAX with volume mixing or tank load pump*Diagram
EQMAX120 bis
page 1 / 7**A. HYDRAULIC DIAGRAM***figure 28 - EQMAX120 bis diagram*

Diagram: EQMAX120 bis

page 2 / 7

B. OPERATING DESCRIPTION

The EQMAX is coupled to a DHW tank, the customer regulates the DHW setpoint he wishes to obtain at the product outlet, which will be the same setpoint for the tank and the EQMAX.

A pump is installed between the tank and the EQMAX that can reactivate the tank loading when the water it contains is lower than the setpoint minus the recovery hysteresis.

The control mechanism of the variable flow pump means that the water leaving the EQMAX rises in temperature more quickly (outflow close to the bottom heel of the pump). The flow is then gradually increased to maintain the burner in operation throughout the DHW loading.

**IMPORTANT:**

When you are in DHW comfort mode (2 cursor on the HMI) the DHW tank loading pump operates permanently, the pump restarts in reduced mode (1 cursor on the HMI) when the temperature in the tank is not satisfactory.

You can choose to operate in permanent comfort mode (2 cursors on the HMI), permanent reduced mode (1 cursor on the HMI), or a timer program to alternate comfort and reduced modes (2 cursors on the HMI + timer program).

This pump operates during anti-legionella cycles to obtain a uniform water temperature in the storage tank.

A timer program can be used to perform loading at either the comfort DHW setpoint or at the reduced DHW setpoint.

**IMPORTANT:**

Check that the loop flow rate and temperatures comply with the regulations; if necessary, adjust the loop circulator adjustment valve and/or the mixing tap setpoint.

In principle, the circulator between the tank and the EQMAX is dimensioned to ensure a flow rate equal to $P / (1.16 \times \Delta T)$

- with P being the nominal power of the EQMAX (in kW) and

- ΔT = setpoint T – cold water T considering the temperature of cold water in summer.

However, it is imperative that this flow rate is higher than the loop return flow rate in the tank, once you are sure of compliance with distribution loop regulations.

It should be remembered that the power of the EQMAX must be determined on the basis of DHW consumption but also taking into account the heat losses of the distribution loop.

The EQMAX's regulator will control the speed of the circulator; based particularly on the return temperature and the instantaneous partial power, the circulator's flow rate will be adjusted to maintain a flow temperature equal to the setpoint temperature, meaning that the electrical power absorbed by the circulator will be minimised.

In summary, the circulator's maximum speed must be set to ensure a flow rate that is at least equal to the loop return flow rate in the tank, so that the minimum speed setting can correspond to the low limit speed of the circulator.

C. CUSTOMER'S ELECTRICAL CONNECTION




Diagram: EQMAX120 bis

page 4 / 7

D. SPECIFIC START-UP PROCEDURE

☞ Correctly install and connect the electrical connections.

☞ Make the settings below in "specialist" mode

 Short press

 Press 3 seconds





End user Commissioning **Specialist** OEM

- Time and date menu

Set time

Set the date

Set the year

- Configuration menu

Configure EQMAX with an additional tank

Configure the alarm output

Configure the DHW tank pump output (variable flow)

Configure the DHW tank pump control direction (variable flow)

Line No. Value

Hour / minute (1) HH.MM

Day / month (2) DD.MM



Year (3) YYYY

DHW tank heating gas (5741) Start

Relay output QX1 (5890) Alarm output K10

Func. Output UX21 Module 1 UX21 (6240) DHW pump Q3

Out. Logic sign Ux21 mod.1 (6241) Standard (most common) or reversed depending on the pump used



- Heating gas menu DHW

Adjust the comfort setpoint

Adjust the reduced setting

DHW release request

Comfort setting temperature (1610) ---°C

Reduced setpoint temperature (1612) ---°C

Release (1620) 24/24

Diagram: EQMAX120 bis

page 5 / 7

Setting the anti-legionella cycle (if desired)


Activate the anti-legionella function	Anti-legionella function (1640)	stop / periodic / fixed day of the week
Choice of repetition. From daily to every 7 days. 1640 = periodic	Function anti-legionella periodical (1641)	1 to 7 days
Choice of the day of the week if 1640=fixed weekday	Function anti-legionella day week (1642)	Monday ... Sunday
Anti-legionella launch time	Anti-legionella function time (1644)	00:00
Heating T° setpoint for anti-legionella function	Anti-legionella setpoint (1645)	as needed (°C)
Anti-legionella T° holding time	Anti-legionella function duration (1646)	as needed (min)

• DHW tank menu

Setting the pimp speed (*See next page to determine the thresholds to be filled in*)


DHW pump Q3 start speed	Circ. pump start rot. speed (5108)	depending on pump specification (%)
DHW pump Q3 minimum speed	Min pump rot. speed (5101)	depending on pump specification (%)
DHW pump Q3 maximum speed	Max pump rot. speed (5102)	depending on pump specification (%)
Adjust burner request	Outlet setpoint T° over-value (5020)	+4 °C
DHW restart hysteresis	Differential (5024)	5 °C

- Switch the DHW mode to permanent comfort (as per parameter 1620)



OR

- Switch the DHW regime to permanent reduced



If you want to lower the DHW setpoint (reduced setpoint) for a specific time range, use the following settings

- Heating gas menu DHW
DHW release request

Line No.	Value
Release (1620)	Timer programme 4/DHW

Diagram: EQMAX120 bis

page 6 / 7

- Timer program menu 4/DHW

Choose the programming range

Set the start of the comfort setpoint range

Set the end of the comfort setpoint range

Preselection (560)

e.g.: Monday-Sunday


1st phase ON (561)

e.g.: 06:00 h

1st phase Off (562)

e.g.: 22:00 h

- Switch the DHW mode to permanent comfort (as per parameter 1620)



Refer to the “§Electrical validation” chapter for the regulator input/output tests

Procedure for adjusting the speed of the DHW pump via the HMI


In order to determine the correspondence between the electrical control via the 0-10V signal and the pump's flow rate, use the following procedure for the start, minimum, and maximum speeds. First refer to the description shown section C page 60 to know the minimum and maximum flow rates that you have to adjust. The start speed depends on your pump; it must be between the minimum and maximum speeds that you will set.

This procedure can be implemented provided that:

- The EQMAX is electrically connected.
- The EQMAX and tank have been supplied with water.
- That you are able to see the water flow between the tank and the EQMAX via the adjustment valve and your connected reading case.



Short press



Press 3 seconds

End user

Commissioning

Specialist

OEM

Line No. Value

- Inputs/outputs test menu

Manually control the Ux21 output of the AVS75 module

Test output Ux21 module1 (7780)

0% corresponds to 0V and 100% to 10V





IMPORTANT:

Remember to set this parameter to "---" once the evaluation procedure is finished.

Once you have found the value in % that corresponds to the start, minimum and maximum flow rates, enter these values in parameters 5101, 5102 and 5108.

	Setting 5108 (start speed)	Setting 5101 (minimum speed)	Setting 5102 (maximum speed)
Setting	100% (recommended)	Circulator pump's low limit	P/10 with P, the power of EQMAX in th/h

EQMAX + TANK(S) SEMI-INSTANT
EQMAX and tank(s) with volume mixing
or tank load pumpDiagrams
EQMAX130
EQMAX131
page 1 / 5**A. HYDRAULIC DIAGRAM***figure 29 - EQMAX130 diagram**figure 30 - EQMAX131 diagram*

Diagrams: EQMAX130, EQMAX131

page 3 / 5

D. CUSTOMER'S ELECTRICAL CONNECTION

E. SPECIFIC START-UP PROCEDURE

☞ Correctly install and connect the electrical connections.

☞ Make the settings below in "specialist" mode

 Short press

 Press 3 seconds



End user Commissioning **Specialist** OEM

Line No. Value

• Time and date menu		
Set time	Hour / minute (1)	HH.MM
Set the date	Day / month (2)	DD.MM
Set the year	Year (3)	YYYY
• Configuration menu		
Configure EQMAX with an additional tank	DHW tank heating gas (5741)	Start
Configure the alarm output	Relay output QX1 (5890)	Alarm output K10
Configure the DHW tank pump output	Relay output QX1 (5891)	DHW pump Q3
• Heating gas menu DHW		
Adjust the comfort setpoint	Comfort setting temperature (1610)	---°C
Adjust the reduced setting	Reduced setpoint temperature (1612)	---°C
DHW release request	Release (1620)	24/24

Setting the anti-legionella cycle (if desired)

Activate the anti-legionella function	Anti-legionella function (1640)	stop / periodic / fixed day of the week
Choice of repetition. From daily to every 7 days. 1640 = periodic	Function anti-legionella periodical (1641)	1 to 7 days
Choice of the day of the week if 1640=fixed weekday	Function anti-legionella day week (1642)	Monday ... Sunday
Anti-legionella launch time	Anti-legionella function time (1644)	00:00
Heating T° setpoint for anti-legionella function	Anti-legionella setpoint (1645)	as needed (°C)
Anti-legionella T° holding time	Anti-legionella function duration (1646)	as needed (min)
• DHW tank menu		
Adjust burner request	Outlet setpoint T° over-value (5020)	-4 °C


Diagrams: EQMAX130, EQMAX131

page 4 / 5

DHW restart hysteresis


Differential (5024) | 5 °C

- Switch the DHW mode to permanent comfort (as per parameter 1620)



OR

- Switch the DHW regime to permanent reduced



If you want to lower the DHW setpoint (reduced setpoint) for a specific time range, use the following settings

- Heating gas *menu DHW*
DHW release request


Line No.	Value
Release (1620)	Timer programme 4/DHW

- Timer program *menu 4/dhw DHW*


Choose the programming range
Set the start of the comfort setpoint range
Set the end of the comfort setpoint range

Preselection (560)	e.g.: Monday-Sunday
1st phase ON (561)	e.g.: 06:00 h
1st phase Off (562)	e.g.: 22:00 h

- Switch the DHW mode to permanent comfort (as per parameter 1620)



Refer to the “§Electrical validation” chapter for the regulator input/output tests

EQMAX CASCADE WITHOUT TANK(S)
*Hydraulic cascade of 2 EQMAXs*Diagrams
EQMAX140
page 1 / 4**A. HYDRAULIC DIAGRAM***figure 31 - EQMAX140 diagram***B. OPTIONAL ACCESSORIES REQUIRED**

No accessories needed

Diagram: EQMAX140

page 3 / 4

E. SPECIFIC START-UP PROCEDURE

☞ Correctly install and connect the electrical connections.

☞ Make the settings below in "specialist" mode

 Short press

 Press 3 seconds





End user Commissioning **Specialist** OEM

Line No. Value

• Time and date menu			
Set time	Hour / minute (1)		HH.MM
Set the date	Day / month (2)		DD.MM
Set the year	Year (3)		YYYY
• Configuration menu			
Configure EQMAX with an additional tank	DHW tank heating gas (5741)		Stop
Configure the alarm output	Relay output QX1 (5890)		Alarm output K10
• Heating gas menu DHW			
Adjust the comfort setpoint	Comfort setting temperature (1610)		---°C
Adjust the reduced setting	Reduced setpoint temperature (1612)		---°C
DHW release request	Release (1620)		24/24


Setting the anti-legionella cycle (if desired)

Activate the anti-legionella function	Anti-legionella function (1640)		stop / periodic / fixed day of the week
Choice of repetition. From daily to every 7 days. 1640 = periodic	Function anti-legionella periodical (1641)		1 to 7 days
Choice of the day of the week if 1640=fixed weekday	Function anti-legionella day week (1642)		Monday ... Sunday
Anti-legionella launch time	Anti-legionella function time (1644)		00:00
Heating T° setpoint for anti-legionella function	Anti-legionella setpoint (1645)		as needed (°C)
Anti-legionella T° holding time	Anti-legionella function duration (1646)		as needed (min)
• DHW tank menu			
Adjust burner request	Outlet setpoint T° over-value (5020)		-4 °C
DHW restart hysteresis	Differential (5024)		5 °C

Diagram: EQMAX140


page 4 / 4

- Switch the DHW mode to permanent comfort (as per parameter 1620)



OR

- Switch the DHW regime to permanent reduced



If you want to lower the DHW setpoint (reduced setpoint) for a specific time range, use the following settings

- Heating gas *menu DHW*
DHW release request


Line No.	Value
Release (1620)	Timer programme 4/DHW

- Timer program *menu 4/dhw DHW*

Choose the programming range
Set the start of the comfort setpoint range
Set the end of the comfort setpoint range

Preselection (560)	e.g.: Monday-Sunday
1st phase ON (561)	e.g.: 06:00 h
1st phase Off (562)	e.g.: 22:00 h

- Switch the DHW mode to permanent comfort (as per parameter 1620)



Refer to the “§Electrical validation” chapter for the regulator input/output tests

EQMAX CASCADE WITH TANK(S)

EQMAX cascade with tank, with or without manual bypass of the safety mixing tap for the anti-legionella cycle

Diagrams
EQMAX160
EQMAX161

page 1 / 5


A. HYDRAULIC DIAGRAM

figure 32 - EQMAX160 diagram




figure 33 - EQMAX161 diagram

Diagrams: EQMAX160, EQMAX161

page 3 / 4

E. SPECIFIC START-UP PROCEDURE

- ✎ Electrically assemble and connect the 2 EQMAXs
- ✎ Connect the DHW tank loading pump to the boiler room's electrical cabinet and activate it as soon as the product is switched on.
- ✎ Perform the following settings identically on the 2 EQMAXs from the "specialist" level

 Short press

 Press 3 seconds



End user	Commissioning	Specialist	OEM
----------	---------------	------------	-----

	Line No.	Value
• Time and date <i>menu</i>		
Set time	Hour / minute (1)	HH.MM
Set the date	Day / month (2)	DD.MM
Set the year	Year (3)	YYYY
• Configuration <i>menu</i>		
Configure EQMAX only (without additional tank)	DHW tank heating gas (5741)	Stop
Configure the alarm output	Relay output QX1 (5890)	Alarm output K10
• Heating gas <i>menu DHW</i>		
Adjust the comfort setpoint	Comfort setting temperature (1610)	---°C
Adjust the reduced setting	Reduced setpoint temperature (1612)	---°C
DHW release request	Release (1620)	24/24
Setting the anti-legionella cycle (if desired)		
Activate the anti-legionella function	Anti-legionella function (1640)	stop / periodic / fixed day of the week
Choice of repetition. From daily to every 7 days. 1640 = periodic	Function anti-legionella periodical (1641)	1 to 7 days
Choice of the day of the week if 1640=fixed weekday	Function anti-legionella day week (1642)	Monday ... Sunday
Anti-legionella launch time	Anti-legionella function time (1644)	00:00
Heating T° setpoint for anti-legionella function	Anti-legionella setpoint (1645)	as needed (°C)
Anti-legionella T° holding time	Anti-legionella function duration (1646)	as needed (min)
• DHW tank <i>menu</i>		
Adjust burner request	Outlet setpoint T° over-value (5020)	-3 °C
DHW restart hysteresis	Differential (5024)	5 °C

Diagrams: EQMAX160, EQMAX161


page 4 / 4

- Switch the DHW mode to permanent comfort (as per parameter 1620)



OR

- Switch the DHW regime to permanent reduced



If you want to lower the DHW setpoint (reduced setpoint) for a specific time range, use the following settings

- Heating gas *menu DHW*
DHW release request


Line No.	Value
Release (1620)	Timer programme 4/DHW

- Timer program *menu 4/dhw DHW*

Choose the programming range
Set the start of the comfort setpoint range
Set the end of the comfort setpoint range

Preselection (560)	e.g.: Monday-Sunday
1st phase ON (561)	e.g.: 06:00 h
1st phase Off (562)	e.g.: 22:00 h

- Switch the DHW mode to permanent comfort (as per parameter 1620)



Refer to the “§Electrical validation” chapter for the regulator input/output tests

External commands mode

page 1/ 4

For a product blocking request made by external information with a VF contact

	Line No.	Value
- Configuration menu - Configure input H1 to make an on/off command by dry contact	H1 input function (5950)	Blocked generator, waiting
If you want the blocking command to be effectuated when you CLOSE your contact	Contact H1 action direction (5951)	Operation contact
If you want the blocking command to be effectuated when you OPEN your contact	Contact H1 action direction (5951)	Normally-closed contact (NC)




INFORMATION:

The frost protection function is still ensured even when the EQMAX is blocked.

To switch from “no DHW request” to “DHW request comfort mode”

	Line No.	Value
- Configuration menu - Configure the H1 input	H1 input function (5950)	Switching of heating circuit + DHW operation
If you want "no DHW request" to switch to "DHW request comfort mode" when you CLOSE your contact	Contact H1 action direction (5951)	Operation contact
If you want "no DHW request" to switch to "DHW request comfort mode" when you OPEN your contact	Contact H1 action direction (5951)	Normally-closed contact (NC)

- Switch the DHW mode when stopped



- Activate the DHW request via your dry contact The screen then displays



External commands mode

page 2/ 4

To modify the DHW temperature setpoints via the Modbus bus

	<i>Line No.</i>	<i>Value</i>
There is no need to change settings on the product when using Modbus communication		
• list of the most used modbus points		
Configure DHW comfort mode (R/W)	Modbus address	191 (0xBF) Temperature in tenths of a degree e.g.: 500 (0x01F4) for 50°C
Configure DHW reduced mode (Eco) (R/W)	Modbus address	192 (0xC0) Temperature in tenths of a degree e.g.: 500 (0x01F4) for 50°C
DHW T° (Read only)	Modbus address	194 (0xC2) Temperature in tenths of a degree e.g.: 500 (0x01F4) for 50°C
DHW status (Read only)	Modbus address	196 (0xC4)

External commands mode

page 3/ 4

List of DHW statuses


Register 196 Line No. 8003	Text
3	Safety thermostat
4	Manual mode
17	Under load
23	Antifreeze protection
24	Antifreeze protection
25	Stop
53	Adiabatic cooling
66	Electrical resistance load
67	Overheating other circuit
69	Under load
70	Under load
71	Under load
75	Under load
77	Adiabatic cooling
78	Adiabatic cooling
79	Cooling protection
80	Loading time too long
81	DHW load blocked
82	DHW load blocked
83	Overheating other circuit
84	Overheating other circuit
85	Overheating other circuit
86	Overheating other circuit
87	Electrical resistance load
88	Electrical resistance load
89	Electrical resistance load
90	Electrical resistance load
91	Electrical resistance load
92	Under load
93	Under load
94	Under load
95	Under load
96	Under load
97	Under load
98	Under load
99	Under load
100	Under load
199	Fluid decanting regime
200	Ready
201	Under load
221	Heat maintenance mode
222	Heat maintenance mode
223	Antifreeze protection

9. ELECTRICAL VALIDATION

EQMAX

	Line No.	Value
• Menu <i>Input / output tests</i>		
Check the sensor values		
<i>DHW sensor B3</i>	<i>External T° B9 (7750)</i>	---°C
Enable outputs		
<i>Alarm output</i>	<i>Relay test(7700)</i>	Output QX1
<i>Programmable output QX2</i>	<i>Relay test(7700)</i>	Output QX2
<i>Cancel activation</i>	<i>Relay test(7700)</i>	No test
Check input H1		
<i>Input used for generator blocking or switching DHW regimes</i>	<i>Status of contact H1(7841)</i>	Closed

10. OPTIMISATION




A. TEMPERATURE CONTROL ACCESSORIES REQUIRED

	Quantity	Appliance reference
Immersed temperature sensor	1	Sensor QAD36

B. OPERATING DESCRIPTION


This kit allows you to monitor the temperature of a secondary hot water loop. You can read the value of this temperature at parameter 8835 and set an alarm that will be stored in the fault history. The temperature of the secondary loop is considered as correct if the level of deviation from the setpoint is less than 1K. If the loop temperature setpoint is reduced by more than 4K, the supervision function is disabled until the secondary loop temperature is dropped back to the new setpoint.



CAUTION :

The alarm to monitor this temperature does not create a product shutdown.
The alarm setting step is one hour.
Monitoring becomes active only once the secondary return temperature reaches setpoint at least once.
Only a single loop can be monitored by this function.

C. CUSTOMER'S ELECTRICAL CONNECTION



D. SPECIFIC START-UP PROCEDURE

	Line No.	Value
- Configuration menu - Configure the secondary loop monitoring temperature sensor	Sensor input Bx3 (5932)	DHW flow temperature sensor B39
- Heating gas <i>menu DHW</i> - Choose setpoint for DHW secondary loop	Flow temperature setpoint (1663)	__ °C
- Choose trigger timeout of the alarm	Secondary loop alarm timeout (1668)	__ hour (--- = inactive, if a value is set, the function becomes automatically active)
- Menu Diagnostic consumer - Check reading of the secondary loop flow sensor	DHW flow temperature (8835)	__ °C




IMPORTANT :


This kit does not guarantee that the installation complies with local regulations (risk of burns, legionella prevention, etc ...)



11. SPARE PARTS LIST




Item	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
		20 to 30 kW	35 to 60 kW	70 to 120 kW
001	Top cover	555346	555361	555362
002	Cable passage plate	555369		
003	Cladding screen	556597	556598	556599
004	Cladding screws	555370		
005	Cladding jacket	555378	555379	555380
006	Lower anode cover	NA	555372	
007	Inspection hatch cover	555371		
008	Collar kit + gas plates	555381		




Item	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
		20 to 30 kW	35 to 60 kW	70 to 120 kW
101	Tank insulating wedge	555432		
102	Upper tank insulation	555424	555427	555431
103	Outlet tapping insulation	555434	555435	555437
104	Tapping plugs	555384	555385	555386
105	Complete exhaust nozzle	555396	555397	555398
106	Exhaust outlet seal + screws	555399	555400	555401
107	Smoke sensor	555395		
108	Exhaust sampling plug	555391		
109	Air/exhaust connection seal	555392	555393	555394
110	Horizontal anode LG = 247mm	NA	555422	
111	Inspection hatch	555387		
112	Inspection hatch screws	555389		
113	Inspection hatch seal	555388		
114	Vertical anode LG = 547 mm	555421		
115	Submerged sensor kit	555583		
116	Condensate siphon	555471		555473
117	Bypass plug	NA	555405	NA
118	Siphon holder SG LXX	NA		555477
119	Siphon hose SG LXX	NA		555478


Models SXX and MXX










Model LXX



Models SXX and MXX




Model LXX




Item	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
		20 to 30 kW	35 to 60 kW	70 to 120 kW
201	Cable passage plate	555369		
202	Panel rear bracket	555476		
203	Panel lock	555485		
204	Panel left side jacket	NA	555474	555475
205	Ignition transformer ZAG1	555584		
206	CEM filter	NA	555504	
207	Right front side jacket	NA		555453
208	Air pressure switch	555585		
209	Panel right rear side jacket	NA		555463
210	Electromagnet + screws	555418		
211	Complete air inlet	555406	555407	555409
212	Air inlet seal	NA		555419
213	Panel right side jacket	555451	555452	NA
214	Air sleeve	555411	555412	555413
215	Air sleeve fixings	555414		555417
216	Air hose fixed ring	NA		555464
----	Versilic (set)	555587	555588	555589


Models SXX




Models MXX and LXX-





Item	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
		20 to 30 kW	35 to 60 kW	70 to 120 kW
301	Control panel sheet	555537	555538	
302	Mini LMS board	20kW: 555486 25kW: 555487 30kW: 555488	35kW: 555489 50kW: 555491 60kW: 555492	70kW: 555493 80kW: 555494 100kW: 555495 120kW: 555496
303	Thumbwheel buttons (x2)	555540		
304	ACI board	555498	555499	555500
305	Round fuse holder	555505		
306	Power connector	555507		
307	Fuses T6.3A 5x20 (box of 10)	555506		
308	Board holding clips (x5)	555503		



Item	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
		20 to 30 kW	35 to 60 kW	70 to 120 kW
401	Complete Navistem display	555438		
402	Mounting + Navistem led board	555439		
403	AVS37 ribbon cable	555444		
404	AVS37 display + thumbwheel	555441		
405	HMI plastic thumbwheel	555443		
406	Main switch	555442		
407	Support plate AVS37	555445		555449
---	Power supply cable	555508		
---	Power cable	555509	555510	555511
---	Signal cable	555513	555515	555517
---	Intermed cable sensor	555520	555523	555524
---	Flue temp sensor	555526	555527	555529
---	Gas valve cable	NA	555530	555532
---	Grounding cable	555533		
---	Carton accessoires	555593		70kW : 555594 80-120kW : 555595



Item	Description	EQMAX SXX	EQMAX MXX	EQMAX LXX
		20 to 30 kW	35 to 60 kW	70 to 120 kW
501	Ignition electrode	555554		555556
502	Ionisation electrode	555553		
503	Flame viewer	555571		555572
504	Burner flange	555569		555570
505	Burner tube	555575	555576	555577
506	Fan	555564	555565	555566
507	Venturi	555557	555559	555560
508	Propane injector	555545	NA	555546
509	Quick connect clip	555561		NA
510	Gas valve	555541	555543	555544
511	Gas line	555547	555548	555549
512	Complete burner	555579	555581	555582
513	Fan support flange	555567		555568
514	Burner seal set	555573		555574
515	Fan seal set	555550		555551
516	Venturi/fan flange	NA	555562	555563
517	Gas valve elbow flange	NA		555552



12. CUSTOMER REGULATION PARAMETERS TABLE

Model: Project reference :

serial no:

Please transfer all parameter modifications into this document!

Note: The "access" column indicates the level of accessibility to information for programming (U for end user, M for commissioning and S for specialist). The *Commissioning* accessibility level integrates the *End User* level. In the same way, the *Specialist* level integrates the *Commissioning* level.

Line No.	Programming	Access	Default value	Customer setting
Time setting				
1	Hours / minutes	U	00:00	
2	Day / month	U	dd.mm	
3	Year	U	yyyy	
5	Start of summer time	U	dd.mm	
6	End of summer time	M	dd.mm	
User interface				
20	Language	U	English	
22	Temporary	M	info	
26	Operation locking	M	stop	
27	Programming locking	M	stop	
28	Direct adjustment	M	with validation	
29	Units	U	°C, bar	
42	Assignment appliance 1	M	---	
44	Heating circuit 2 operation	M	---	
46	Heating circuit 3/P operation	M	---	
70	Software version	M	---	
Time program 4: Domestic hot water (DHW) production				
561	1st period start time	U	06:00	
562	1st period stop time	U	22:00	
563	2nd period start time	U	---	
564	2nd period stop time	U	---	
565	3rd period start time	U	---	
566	3rd period stop time	U	---	
576	Default values	U	---	
Timer programme 5				
601	1st period start time	U	06:00	
602	1st period stop time	U	22:00	
603	2nd period start time	U	---	
604	2nd period stop time	U	---	
605	3rd period start time	U	---	
606	3rd period stop time	U	---	
616	Default values	U	---	

Line No.	Programming	Access	Default value	Customer setting
DHW gas heating				
1610	Comfort setpoint	U	65 °C	
1612	Reduced setpoint	U	65 °C	
1614	Max comfort setpoint	S	80 °C	
1620	Release	M	24/24	
1640	Anti-legionella function	S	stop	
1641	Periodic anti-legionella function	S	1	
1642	Anti-legionella function day week	S	Monday	
1644	Anti-legionella function hour	S	0 min.	
1645	Anti-legionella setpoint	S	80 °C	
1646	Anti-legionella function duration	S	10 min	
1663	Circulation setpoint	S	55 °C	
1668	Loop alarm times	S	01:00	
1680	DHW regime switching	S	stop	
2570	Max. output by lim. output	S	50%	
2571	Output lim. differential	S	2 °C	
5741	DHW tank heating gas	S	stop	
6745	DHW loading alarm time	S	08:00	
Boiler				
2210	Min setpoint	S	8 °C	
2212	Max. setpoint	S	85 °C	
2214	Manual rate setpoint	U	60 °C	
2217	Frost protection setpoint	S	2 °C	
2243	Burner min stop duration	S	5 min	
2250	Pump timed stop	S	1 min	
2253	DHW supply pump timer stop	S	0 min.	
2321	Rot. speed at boiler on start	S	0%	
2322	Pump speed min boiler	S	0%	
2323	Pump speed max boiler	S	0%	
2324	Pump speed P-band XP boiler	S	16 °C	
2325	Boiler speed integration time	S	30 s	
2326	Boiler speed bypass time	S	5 s	
2330	Nom. power	S	S20: 20 kW S25: 25 kW S30: 30 kW M35: 35 kW M50: 50 kW M60: 60 kW L70: 70 kW L80: 80 kW L100: 100 kW L120: 120 kW	
2331	Power at basic speed	S	SXX: 8 kW MXX: 13 kW LXX: 30 kW	

Line No.	Programming	Access	Default value	Customer setting
2442	Max. charge full fan speed	S	S20: 6030 rpm S25: 7390 rpm S30: 8500 rpm M35: 6250 rpm M50: 8890 rpm M60: 9800 rpm L70: 3810 rpm L80: 4330 rpm L100: 5270 rpm L120: 6400 rpm	
2444	Max DHW fan speed	S	S20: 6030 rpm S25: 7390 rpm S30: 8500 rpm M35: 6250 rpm M50: 8890 rpm M60: 9800 rpm L70: 3810 rpm L80: 4330 rpm L100: 5270 rpm L120: 6400 rpm	
2454	Heating circuit activation differential	S	1 °C	
2455	Min. heating circuit disc. different.	S	1 °C	
2460	DHW activation differential	S	2 °C	
2461	Min DHW disconnection differential	S	5 °C	
2550	Gas energy meter	S	on	
2551	Gas meter correction	S	1	
DHW tank				
5020	Outlet setpoint T° raise	S	-3 °C	
5022	Charge type	S	complete charge	
5024	DHW differential	S	5 °C	
5101	Min pump rot. speed	S	50%	
5102	Max pump rot. speed	S	100%	
5103	Band Pump rotation speed DHW	S	32 °C	
5104	DHW rotation speed integration time	S	120 s	
5105	DHW rotation speed Tv	S	0 s	
5108	Load pump start rot. speed	S	100%	
General functions				
5570	dT° regul on dT 1	S	20 °C	
5571	dT° regul off dT 1	S	10 °C	
5572	Regul min act time dT 1	S	0 °C	
5573	Sensor 1 regulator dT 1	S	none	
5574	Sensor 2 regulator dT 1	S	none	
5575	Min regul on time dT1	S	0 s	
5577	Pump/valve kick-start K21	S	on	
5580	dT° regul on dT 2	S	20 °C	

Line No.	Programming	Access	Default value	Customer setting
5581	dT°regul off dT 2	S	10 °C	
5582	Regul min act time dT 2	S	0 °C	
5583	Sensor 1 regulator dT 2	S	none	
5584	Sensor 2 regulator dT 2	S	none	
5585	Min regul on time dT2	S	0 s	
5587	Pump/valve kick-start K21	S	on	
Configuration				
5890	Relay output QX1	M	Alarm output K10	
5891	Relay output QX2	M	Valve/DHW pump Q3	
5931	Sensor input BX2	M	none	
5932	Sensor input BX3	M	none	
5950	H1 input function	M	none	
5951	H1 contact action direction	M	operation	
6020	Extension module 1 funct	M	none	
6021	Extension module 2 funct	M	none	
6022	Extension module 3 funct	M	none	
6030	Relay output QX21 module 1	M	none	
6031	Relay output QX22 module 1	M	none	
6032	Relay output QX23 module 1	M	none	
6033	Relay output QX21 module 2	M	none	
6034	Relay output QX22 module 2	M	none	
6035	Relay output QX23 module 2	M	none	
6036	Relay output QX21 module 3	M	none	
6037	Relay output QX22 module 3	M	none	
6038	Relay output QX23 module 3	M	none	
6040	Module 1 BX21 sensor input	M	none	
6041	Module 1 BX22 sensor input	M	none	
6042	Module 2 BX21 sensor input	M	none	
6043	Module 2 BX22 sensor input	M	none	
6044	Module 3 BX21 sensor input	M	none	
6045	Module 3 BX22 sensor input	M	none	
6046	Module 1 H2 input function	M	none	
6047	Mod.2 H2 contact act. direction	M	operation	
6049	Mod. 2 H2 voltage value (U1)	M	0V	
6050	Module 1 H2 funct. value 1 (F1)	M	0	
6051	Mod. 1 H2 voltage 2 value 1 (U2)	M	0V	
6052	Module 1 H2 funct. value 2 (F2)	M	0	
6054	Module 2 H2 input function	M	none	
6055	Mod.2 H2 contact act. direction	M	operation	
6057	Mod. 1 H2 voltage value 1 (U1)	M	0V	
6058	Module 2 H2 funct. value 1 (F1)	M	0	
6059	Mod. 2 H2 voltage 2 value (U2)	M	0V	
6060	Module 2 H2 funct. value 2 (F2)	M	0	
6062	Module 3 H2 input function	M	none	
6063	Mod.3 H2 contact act. direction	M	operation	
6065	Mod. 3 H2 voltage value (U1)	M	0V	
6066	Module 3 H2 funct. value 1 (F1)	M	0	

Line No.	Programming	Access	Default value	Customer setting
6067	Mod. 3 H2 voltage 2 value 3 (U2)	M	0V	
6068	Module 3 H2 funct. value 2 (F2)	M	0	
6100	Ext. T° sensor correction	S	0 °C	
6120	Installation antifreeze	S	stop	
6127	Valve/pump kick-start duration	S	30 s	
6200	Register sensor	S	---	
6205	Reset parameters	S	---	
6220	Software version	S	---	
6224	Appliance identification.	S	---	
6230	Info 1 OEM	S	16	
6231	Info 2 OEM	S	S20: 91 S25: 92 S30: 93 M35: 100 M50: 94 M60: 95 L70: 96 L80: 97 L100: 98 L120: 99	
6240	Output function UX21 module 1	S	Q3 gas heating pump	
6241	Logic signal output UX21 module 1	S	standard	
6242	Signal output UX21 module 1	S	0-10V	
6243	Output function UX22 module 1	S	DHW Q4 circulation pump	
6244	Logic signal output UX22 module 1	S	standard	
6245	Signal output UX22 module 1	S	0-10V	
6246	Output function UX21 module 2	S	Q3 gas heating pump	
6247	Logic signal output UX21 module 2	S	standard	
6248	Signal output UX21 module 2	S	0-10V	
6249	Output function UX22 module 2	S	DHW Q4 circulation pump	
6250	Logic signal output UX22 module 2	S	standard	
6251	Signal output UX22 module 2	S	0-10V	
6252	Output function UX21 module 3	S	Q3 gas heating pump	
6253	Logic signal output UX21 module 3	S	standard	
6254	Signal output UX21 module 3	S	0-10V	
6255	Output function UX22 module 3	S	DHW Q4 circulation pump	
6256	Logic signal output UX22 module 3	S	standard	
6257	Signal output UX22 module 3	S	0-10V	
6351	OT function channel 1	S	External room control 1	
6359	DHW external control	S	none	
LPB bus				
6612	Alarm timeout	S	10 min	
Error				
6705	Software diagnostic code	U	0	
6800	History 1	U	00:00	
6805	Software diagnostic code 1	U	0	

Line No.	Programming	Access	Default value	Customer setting
6810	History 2	U	00:00	
6815	Software diagnostic code 2	U	0	
6820	History 3	U	00:00	
6825	Software diagnostic code 3	U	0	
6830	History 4	U	00:00	
6835	Software diagnostic code 4	U	0	
6840	History 5	U	00:00	
6845	Software diagnostic code 5	U	0	
6850	History 6	U	00:00	
6855	Software diagnostic code 6	U	0	
6860	History 7	U	00:00	
6865	Software diagnostic code 7	U	0	
6870	History 8	U	00:00	
6875	Software diagnostic code 8	U	0	
6880	History 9	U	00:00	
6885	Software diagnostic code 9	U	0	
6890	History 10	U	00:00	
6895	Software diagnostic code 10	U	0	
6900	History 11	U	00:00	
6905	Software diagnostic code 11	U	0	
6910	History 12	U	00:00	
6915	Software diagnostic code 12	U	0	
6920	History 13	U	00:00	
6925	Software diagnostic code 13	U	0	
6930	History 14	U	00:00	
6935	Software diagnostic code 14	U	0	
6940	History 15	U	00:00	
6945	Software diagnostic code 15	U	0	
6950	History 16	U	00:00	
6955	Software diagnostic code 16	U	0	
6960	History 17	U	00:00	
6965	Software diagnostic code 17	U	0	
6970	History 18	U	00:00	
6975	Software diagnostic code 18	U	0	
6980	History 19	U	00:00	
6985	Software diagnostic code 19	U	0	
6990	History 20	U	00:00	
6995	Software diagnostic code 20	U	0	
Maintenance / Special operation				
7040	Burner op. hours interval	S	---	
7041	Op. h since maint.	S	0 h	
7042	Burner start interval	S	---	
7043	Burner start since Maint.	S	0	
7044	Maintenance interval	S	---	
7045	Time since maintenance	S	0 months	
7050	Ionis. current fan speed	S	0 rpm	
7051	Ionis. current message	S	no	

Line No.	Programming	Access	Default value	Customer setting
7130	Chimney function	U	stop	
7131	Burner power	U	max. burner load	
7140	Manual mode	U	stop	
7143	Regulator stop function	S	---	
7145	Regulator stop setpoint	S	100%	
7146	Drain function	M	---	
7147	Drain type	M	---	
7170	After Sales Department telephone	M	---	
7250	Pos memory Pstick	S	---	
7252	Pstick control	S	---	
7253	Pstick progress	S	---	
7254	PStick status	S	---	
Inputs/Outputs test				
7700	Relay test	M	---	
7750	DHW temperature B3/B8	U	---	
7760	Boiler T° B2	U	---	
7820	Sensor T° BX1	U	---	
7821	Sensor T° BX2	U	---	
7822	Sensor T° BX3	U	---	
7823	Sensor T° BX4	U	---	
7830	Module 1 BX21 sensor T°	U	---	
7831	Module 1 BX22 sensor T°	U	---	
7832	Module 2 BX21 sensor T°	U	---	
7833	Module 2 BX22 sensor T°	U	---	
7834	Module 3 BX21 sensor T°	U	---	
7835	Module 3 BX22 sensor T°	U	---	
7840	H1 voltage signal	U	---	
7841	H1 contact status	U	---	
7845	Module 1 H2 voltage signal	U	---	
7846	Module 1 H2 contact status	U	---	
7848	Module 2 H2 voltage signal	U	---	
7849	Module 2 H2 contact status	U	---	
7851	Module 3 H2 voltage signal	U	---	
7852	Module 3 H2 contact status	U	---	
7860	H4 contact status	U	---	
7872	H6 contact status	U	---	
7874	H7 contact status	U	---	
Status				
8003	DHW status	U	---	
8005	Boiler status	U	---	
8009	Burner status	U	---	
Generator diagnostic				
8304	Boiler pump status (Q1)	S	---	

Line No.	Programming	Access	Default value	Customer setting
8308	Boiler pump speed	S	---	
8310	Boiler temperature	U	---	
8311	Boiler setpoint	U	---	
8312	Boiler switching point	M	---	
8313	Regulation sensor	M	---	
8314	Boiler return temperature	U	---	
8316	Fume temperature	U	---	
8318	Max burnt gas temperature	U	---	
8323	Fan speed	U	---	
8324	Burner fan setpoint	U	---	
8325	Current fan command	M	---	
8326	Boiler modulation	U	---	
8329	Ionisation current	U	---	
8330	1st speed operating hours	U	---	
8331	1st speed start counter	U	---	
8339	DHW mode operating hours	U	---	
8379	Global DHW energy	S	---	
8380	Global energy	S	---	
8382	DHW gas energy	S	---	
8383	Gas energy	U	---	
8390	Current phase No.	S	---	
Consumer diagnostic				
8820	DHW pump	U	---	
8823	DHW intermediate circuit pump status (Q33)	U	---	
8825	DHW pump speed	U	---	
8826	Interm. circulator pump speed DHW	U	---	
8830	DHW temperature 1 (B3)	U	---	
8831	DHW setpoint	U	---	
8832	DHW temperature 2 (B31)	U	---	
8835	DHW circulation temperature	U	---	
8836	DHW loading temperature	U	---	
9016	Special temperature 1	U	---	
9017	Special temperature 2	U	---	
9031	Relay output QX1	U	---	
9032	Relay output QX2	U	---	
9033	Relay output QX3	U	---	
9050	Relay output QX21 module 1	U	---	
9051	Relay output QX22 module 1	U	---	
9052	Relay output QX23 module 1	U	---	
9053	Relay output QX21 module 2	U	---	

Line No.	Programming	Access	Default value	Customer setting
9054	Relay output QX22 module 2	U	---	
9055	Relay output QX23 module 2	U	---	
9056	Relay output QX21 module 3	U	---	
9057	Relay output QX22 module 3	U	---	
9058	Relay output QX23 module 3	U	---	
Safety unit				
9504	Preventilat. speed setpoint	S	SXX: 5100 rpm MXX: 5000 rpm LXX: 3300 rpm	
9505	Min. pre-ventilation setpoint speed	S	SXX: 5100 rpm MXX: 5000 rpm LXX: 3300 rpm	
9506	Nominal load tolerated speed	S	SXX: 300 rpm MXX: 300 rpm LXX: 500 rpm	
9512	Ignition speed setpoint	S	SXX: 5840 rpm MXX: 3870 rpm LXX: 3300 rpm	
9513	Maximum ignition speed setpoint	S	SXX: 5920 rpm MXX: 3870 rpm LXX: 500 rpm	
9514	Ignition rot. speed tolerance	S	200 rpm	
9524	Part charge rot. speed setpoint	S	SXX: 2200 rpm MXX: 2250 rpm LXX: 1700 rpm	
9525	Part char. speed min setpoint	S	SXX: 2320 rpm MXX: 2200 rpm LXX: 1620 rpm	
9529	Nom char. speed setpoint	S	S20: 6030 rpm S25: 7390 rpm S30: 8500 rpm M35: 6250 rpm M50: 8890 rpm M60: 9800 rpm L70: 3810 rpm L80: 4330 rpm L100: 5270 rpm L120: 6400 rpm	
9530	Nom charge max speed setpoint	S	S20: 6030 rpm S25: 7390 rpm S30: 8500 rpm M35: 6250 rpm M50: 8890 rpm M60: 9800 rpm L70: 3810 rpm L80: 4330 rpm L100: 5270 rpm L120: 6400 rpm	

Line No.	Programming	Access	Default value		Customer setting
9626	Power slope/fan speed	S	G20	G31	
			S20:	301.6	133.3
			S25:	296.6	174.5
			S30:	283.8	143.0
			M35:	178.6	161.0
			M50:	178.0	147.8
			M60:	163.4	146.7
			L70:	54.5	49.6
			L80:	54.2	43.4
			L100:	52.7	46.0
			L120:	53.3	47.6
9627	Section Y fan power/speed	S	G20	G31	
			S20:	-1.5	1033.3
			S25:	-24.3	-12
			S30:	-13.5	-17
			M35:	0	-6.15
			M50:	-10.8	-8.9
			M60:	-5.2	0.0
			L70:	-6.5	-1.8
			L80:	-8.1	-4.2
			L100:	-3.3	-5.9
			L120:	-1.8	-6.3
9650	Chimney drying	S	0		
9651	Chimney drying speed setpoint	S	SXX:	2100 rpm	
			MXX:	2250 rpm	
			LXX:	1600 rpm	
9652	Chimney drying time	S	10 min		

13. ANNEXE A PRODUCT FICHE

Product Fiche ≤ 400 kW

Product reference		
Commercial brand		
Model		
Nominal power	Prated	kW
Useful heat generation		
At rated power and under 80°C / 60°C operating conditions	P ₄	kW
	η ₄ (PCS)	%
At 30% of rated power and with a return temperature of 30°C	P ₁	kW
	η ₁ (PCS)	%
Auxiliary power consumption		
At full capacity	elmax	kW
At partial capacity	elmin	kW
In standby mode	P _{SB}	kW
Other features		
Heat loss	Pstby	kW
Nitrogen oxide emissions	Nox (PCS)	mg/kWh



WEEE DIRECTIVE 2012/19/EU
Waste Electrical and Electronic Equipment Directive

- At the end of the product life, dispose of the packaging and product in a corresponding recycle centre.
- Do not dispose of the unit with the usual domestic refuse.
- Do not burn the product.
- Remove the batteries.
- Dispose of the batteries according to the local statutory requirements and not with the usual domestic refuse.



At Ideal Heating we take our environmental impact seriously, therefore when installing any Ideal Heating product please make sure to dispose of any previous appliance in an environmentally conscious manner. Households can contact their local authority to find out how. See <https://www.gov.uk/managing-your-waste-an-overview> for guidance on how to efficiently recycle your business waste.

Technical Training

Our Expert Academy offer a range of training options designed and delivered by our experts in heating. For details please contact:
expert-academy.co.uk

Ideal Boilers Ltd., pursues a policy of continuing improvement in the design and performance of its products. The right is therefore reserved to vary specification without notice.

Ideal is a trademark of Ideal Boilers.

Registered Office

Ideal Boilers Ltd., National Avenue, Hull, East Yorkshire, HU5 4JB

Tel 01482 492251 Fax 01482 448858

Registration No. London 322 137

EU Authorised Representative:

Atlantic SFDT

44 Boulevard des Etats-Unis, 85 000 La Roche-Sur-Yon, France

+33 (0)2 51 44 34 34

Ideal Commercial Technical Helpline: 01482 498376

Ideal Parts: 01482 498665

idealheating.com

ideal
HEATING